



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		806867A 3	EXHAUST MANIFOLD	1		
2	22	32802	PIPE PLUG (1/8-27)	1		
3	22	36382	PIPE PLUG (1/4-18)	1		
4	10	53728	SCREW (4-5/8")	2		
4A	16	806300	STUD	3		
5	12	20553	WASHER	3		
5A	11	46335	NUT	3		
9		73813A 1	END CAP/LIFTING EYE (REAR)	2		
10	27	73814 1	GASKET	2		2
11	10	824941	SCREW (3/4")	8		
13	27	815528	GASKET	1		
14		12076A 2	EXHAUST RISER ASSEMBLY	1		
15	27	99777 2	GASKET	1		2
16	10	66863 1	SCREW	2		
17	32	42850 64	HOSE INLET (3/4" I.D.)	1	W/O POWER STEERING	
18	54	815504412	CLAMP	2	W/O POWER STEERING	
19	32	815413	HOSE, COOLER TO DRIVE UNIT	1	W/ POWER STEERING	
20	32	806433	HOSE, COOLER TO HOUSING	1	W/ POWER STEERING	
21	54	815504220	CLAMP	2	W/ POWER STEERING	
22	54	815504412	CLAMP	2	W/ POWER STEERING	
23		99356A 1	OIL COOLER	1	W/ POWER STEERING	
24	54	815504232	CLAMP	1	W/ POWER STEERING	
25		805546A 2	BRACKET	1	W/ POWER STEERING	
25A		77223 3	PAD	1	W/ POWER STEERING	
25B	10	816585	SCREW	1	W/ POWER STEERING	
26		47587A 2	HOUSING ASSEMBLY	1		
27	22	32803	PIPE PLUG	1		
28	22	32802	PIPE PLUG	1		
29	27	814680	GASKET	1		2
30	10	90059	SCREW (7/8")	1		
30	10	90187	SCREW (1-1/4")	1		
31	22	42853	ELBOW	1		
32		59078	THERMOSTAT	1		
33	27	47590 1	GASKET	1		2
34		60372A 2	COVER ASSEMBLY	1		
35	10	79654	SCREW (2-3/8")	2		
36	54	805628T	LIFTING EYE	1		
37	32	806993	HOSE, HOUSING TO MANIFOLD	1		
38	54	815504220	CLAMP	2		
39	32	96879	HOSE, HOUSING TO WATER PUM	1		
40	54	815504220	CLAMP	2		