



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	860217A	2 HARNESS-WIRING	1	5.7L ALPHA/BRAVO	
1	84	860216A	2 HARNESS-WIRING	1	5.7LX ALPHA/BRAVO & 350 MAG	
2		26079A	2 PLATE KIT	1		
3	10	15001	SCREW (#8-16 X 7/8 IN.)	4		
4		805383T	BRACKET-HARNESS MOUNTING	1		
5	11	32219	NUT (3/8-16)	1		
6	22	805328	1 ELBOW-90 DEG. (1/8 IN.)	1		
7		815425	SENDER-OIL PRESSURE	1		
7		37293	SENDER-OIL PRESSURE	OPT	DUAL STATION	4
8		97257A	1 SENDER-WATER TEMPERATUR	1		
8		49734A	1 SENDER-WATER TEMPERATUR	OPT	DUAL STATION	4
9	13	26996	LOCKWASHER (#10)	2		
10	11	68219	NUT (#10-32)	2		
11	87	806951	SWITCH-WATER TEMPERATURE	1	AUDIO WARNING SYSTEM	
12	22	805059	BUSHING-REDUCER	1	AUDIO WARNING SYSTEM	
13	87	805605A	1 SWITCH-OIL PRESSURE	1	AUDIO WARNING SYSTEM	
14		816492A	6 ALARM KIT	1	AUDIO WARNING SYSTEM	
15		805368T	BRACKET-MOUNTING	1		
16	88	806950	BREAKER-CIRCUIT (50 AMP)	1		
17	10	68513	SCREW (#10-32 X 3/8 IN.)	2		
18	13	26996	LOCKWASHER (#10)	2		
19	10	57583	SCREW (#8-32 X 3/8 IN.)	2		
20	89	96158	SOLENOID-STARTER	1		
21	10	805564	SCREW (1/4-20)	3	ALPHA ENGINES	
21	10	805564	SCREW (1/4-20)	2	BRAVO ENGINES	
22	16	805459	STUD	1	BRAVO ENGINES	
23	13	26992	LOCKWASHER (1/4 IN.)	2		
24	11	94330	NUT (1/4-20)	2		
25	13	26996	LOCKWASHER (#10)	2		
26	11	68219	NUT (10-32)	2		
27	85	97861	INSULATOR-STARTER SOLENOI	1		
28	84	95084A	9 CABLE ASSEMBLY	1	BRAVO ENGINES	
29	88	79091	FUSE (20 AMP)	1	BRAVO ENGINES	
30	84	95084A10	CABLE ASSEMBLY	1	BRAVO ENGINES	
31		807763T	BRACKET	1		
32	10	806835	SCREW (#10-32 X 1/2 IN.)	2		
33		807264T	3 MODULE-IGNITION CONTROL	1	5.7L ALPHA	
33		807645T	3 MODULE-IGNITION CONTROL	1	5.7L BRAVO	
33		806957T	4 MODULE-IGNITION CONTROL	1	5.7LX ALPHA AND 350 MAGNUM	
33		806956T	4 MODULE-IGNITION CONTROL	1	5.7LX BRAVO	
33		808066T	2 MODULE-IGNITION CONTROL	1	5.7LX ALPHA SWISS EMISSION	