



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	806217A10	WIRING HARNESS	1		
2		26079A 2	PLATE ASSEMBLY	1		
3	10	15001	SCREW	4		
4		805468T	MOUNTING BRACKET	1		
5		815425	OIL PRESSURE SENDER	1		
5		37293	OIL PRESSURE SENDER	OPT	(DUAL STATION)	7
6		97257A 1	WATER TEMPERATURE SENDEI	1		
6		49734A 1	WATER TEMPERATURE SENDEI	OPT	(DUAL STATION)	7
7	13	26996	LOCKWASHER	2		
8	11	68219	NUT	2		
9	22	48556	BUSHING	1		
10	22	42554	NIPPLE	1		
11	22	46932	ELBOW	1		
12		805368T	MOUNTING BRACKET	1		
13	88	11178	CIRCUIT BREAKER (50AMP)	1		
14	10	45862	SCREW (7/8 IN.)	2		
15	11	61356	NUT	2		
16	13	26996	LOCKWASHER	2		
17	11	68219	NUT	2		
18	89	96158	STARTER SOLENOID	1		
19	10	805564	SCREW	2		
20	13	26992	LOCKWASHER (1/4)	2		
21	11	94330	NUT (1/4-20)	2		
22	13	26996	LOCKWASHER (#10)	2		
23	11	68219	NUT (10-32)	2		
24	85	97861	INSULATOR	1		
25		805361T 2	IGNITION MODULE	1	(7.4L BRAVO I/II & 454 MAGNUM	
25		805361T 6	IGNITION MODULE	1	(7.4L BRAVO III)	
26	84	805363A 1	HARNESS	1		
27	10	12110	SCREW	2		
28	16	805459	STUD	1		
29	11	46438	NUT	1		
30	10	805565	SCREW	1		