



1606

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		26079A 2	PLATE KIT, Wire Harness Mount	1		
2	10	15001	SCREW, (#8-16 x .875)	4		
3		863440T	BRACKET, Harness Mounting/Lift	1		
4	10	98261	SCREW, (.375-16 x .750)	2		
5		864271T 3	MODULE ASSEMBLY, ECM	1	(5.0L MPI Alpha)	1
5		864376T 3	MODULE ASSEMBLY, ECM	1	(5.0L MPI Bravo)	1
5		864272T 3	MODULE ASSEMBLY, ECM	1	(350 Mag MPI Alpha)	1
5		864377T 3	MODULE ASSEMBLY, ECM	1	(350 Mag MPI Bravo)	1
5		864273T 3	MODULE ASSEMBLY, ECM	1	(MX6.2L MPI)	1
6	10	821300 25	SCREW, (M6 x 25)	3		1
7	12	65567	WASHER, (.265 x .750 x .048)	3		
8	25	834985	GROMMET	3		
9	23	856954	BUSHING	3		
10		863424	BRACKET, ECM Mounting	1		
11	10	860008	SCREW, Torx (.250-20 x .625)	3		
12	84	863433T 1	WIRING HARNESS	1		1
13	54	804351	CLIP, Relay Mounting	2		
14	54	804352	CLIP, Fuse Block Mounting	1		
15		883562	COVER, Fuse	1		
16		807057T	RELAY	2		
17	88	832969 20	FUSE, Mini (Yellow - 20 Ampere)	3		
18		805368T	BRACKET, Electrical, Mounting	1		
19	88	806950	CIRCUIT BREAKER, (50 Ampere)	1		
20	13	26996	LOCKWASHER, (#10)	2		
21	10	68513	SCREW, (#10-32 x .375)	2		
22	10	57583	SCREW, (#8-32 x .375)	2		
23	89	96158T	SOLENOID, Starter	1		
24	13	26995	LOCKWASHER, (#8)	2		
25	11	26419	NUT, (#8-32)	2		
26	10	805564	SCREW, (.250-20 x .750)	1		
27	13	26992	LOCKWASHER, (.250)	2		
28	11	94330	NUT, (.250-20)	2		
29	85	97861	INSULATOR, Starter Solenoid	1		
30		816492A 6	ALARM KIT	1		
31	84	95084A 9	CABLE ASSEMBLY, (91.00 Inches)	1	(Bravo)	
32	88	79091	FUSE, (20 Ampere)	1	(Bravo)	
33	84	95084A 10	CABLE ASSEMBLY, (5.00 Inches)	1	(Bravo)	
34		864337A 1	CONNECTOR, Jumper	1	(Black Wire)	
35	84	862262A 2	HARNESS ASSEMBLY	1	(Boost Pump)	