

NO IMAGE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
0	91	822608	6 DDT CARTRIDGE	1		
0	84	822560A	5 EFI TEST HARNESS	1	(ELECTRICAL/IGNITION)	
0	84	825003A	1 HARNESS	1	(ELECTRICAL/IGNITION)	
0	91	823686A	2 IGNITION DIAGNOSTIC UNIT	1	(ELECTRICAL/IGNITION)	
-	91	99750A	1 MULTI METER/DVA TESTER	1	(ELECTRICAL/IGNITION)	
0	91	52024A	1 REMOTE STARTER SWITCH	1	(ELECTRICAL/IGNITION)	
0	91	59339	1 SERVICE TACHOMETER	1	(ELECTRICAL/IGNITION)	
0	91	850439T	1 SPARK GAP TESTER - EIGHT CH	1	(ELECTRICAL/IGNITION)	
0	91	63998A	1 SPARK GAP TESTER - SINGLE CH	1	(ELECTRICAL/IGNITION)	
0	91	825824A	2 TACK INTERFACE MODULE	1	(ELECTRICAL/IGNITION)	
0	91	99379	1 TIMING LIGHT	1	(ELECTRICAL/IGNITION)	
0	91	11230	1 ALIGNMENT TOOL	1	(TRIM/TILT SYSTEM)	
0	91	99750A	1 MULTI-METER DVA TESTER	1	(TRIM/TILT SYSTEM)	
0	91	52915A	6 POWER TRIM TEST GAUGE KIT	1	(TRIM/TILT SYSTEM)	
0	91	74951	1 SPANNER WRENCH	1	(TRIM/TILT SYSTEM)	
0	91	44487T	1 TRIM ROD GUIDE REMOVER TO	1	(TRIM/TILT SYSTEM)	
0	91	44486A	1 TRIM ROD REMOVAL TOOL	1	(TRIM/TILT SYSTEM)	
0	91	29287	1 COMPRESSION TESTER	1	(POWERHEAD)	
0	91	55919	1 DRIVER HEAD	1	(POWERHEAD)	
0	91	52344	1 FLYWHEEL HOLDER	1	(POWERHEAD)	
0	91	73687A	2 FLYWHEEL PULLER	1	(POWERHEAD)	
0	91	90455T	1 LIFTING EYE	1	(POWERHEAD)	
0	91	93004A	2 LOCK RING INSTALLATION TOOL	1	(POWERHEAD)	
0	91	52952T	1 LOCK RING REMOVAL TOOL	1	(POWERHEAD)	
0	91	24697	1 PISTON RING EXPANDER	1	(POWERHEAD)	
-	91	92973A	1 PISTON PIN TOOL	1	(POWERHEAD)	
0	91	812549T	1 POWERHEAD STAND	1	(POWERHEAD)	
0	91	24161	1 PROTECTOR CAP-FLYWHEEL	1	(POWERHEAD)	
-	91	823237T	1 RING COMPRESSOR	1	(POWERHEAD)	
0	91	66274	1 TORQUE WRENCH (0-150 LB. IN.)	1	(POWERHEAD)	
0	91	37241	1 UNIVERSAL PULLER PLATE	1	(POWERHEAD)	
0	91	852087A	3 DUAL FUEL/AIR PRESSURE GAL	1	(DFI)	
0	10	40073	25 SCREW (5 X 25 MM)	1	(DFI)	
0	91	851980	1 SEAL/TEFLON RING INSTALLATI	1	(DFI)	
0	91	851980	1 SEAL/TEFLON RING SIZING TOC	1	(DFI)	
0	91	16850A	7 SINGLE FUEL/AIR PRESSURE G	1	(DFI)	
0	91	99750A	1 VOLT/OHM METER	1	(DFI)	