



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	936	898101873	CYLINDER HEAD	1		
2		898101881	SEAT	4		
3	27	898101872	GASKET	1		
4		898101890	VALVE, Intake	4		
5		898101889	VALVE, Exhaust	4		
6		898101887	ROTATOR	4		
7	26	898101886	SEAL	8		
8	24	898101885	SPRING	8		
9		898101883	CAP	8		
10	28	898101882	KEY	16		
11		898101880	ROCKER ARM	8		
12		898101884	ADJUSTER, Valve Adjuster	8		
13	16	8M2003551	STUD, (M8 x 1.25 x 44)	9		
14		898101881	SEAT	8		
15	11	826365	NUT, (M8)	9		
16	16	8M2003551	STUD, (M8 x 1.25 x 44)	8		
17	11	826365	NUT, (M8)	8		
18		879150006	HOUSING ASSEMBLY, With Hous	1		
19	10	879150007	SCREW, (M8 x 18)	2		
20	10	898101867	SCREW	10		
21		879150065	SENSOR, Temperature	1		
22		898101888	SEAT	8		
23		898101875	VALVE SEAT, Exhaust	4		
23		898101874	VALVE SEAT, Exhaust (4 mm)	AR		
23		898101876	VALVE SEAT, Intake	4		
23		898101877	VALVE SEAT, Intake (2 mm)	AR		
23		898101878	VALVE SEAT, Intake (4 mm)	AR		