



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		807323A 5	ELECTRICAL BOX	1		
2		806762A 1	VELCRO KIT	1		
3		806611T	KNOCK MODULE	1		
4	11	64015	NUT	1		
5	89	96054	STARTER SOLENOID	1		
6	13	26995	LOCKWASHER (#8)	2		
7	11	26419	NUT (8-32)	2		
8	13	26992	LOCKWASHER (1/4 IN.)	2		
9	11	94330	NUT (1/4-20)	2		
10	12	35462	WASHER	2		
11	11	64015	NUT	2		
12	85	97861	INSULATOR	1		
13	88	11178	CIRCUIT BREAKER	1		
14	10	45862	SCREW	2		
15	11	61356	NUT	2		
16	13	26996	LOCKWASHER	2		
17	11	68219	NUT	2		
18		805615A 2	THUMB SCREW	1		
19	23	806981	SPACER	3		
20	12	35462	WASHER	3		
21	11	64015	NUT	3		
22		807646T 2	ECM MODULE	1		
23	10	76596	SCREW	4		
24	12	20533	WASHER	4		
25	11	805562	NUT	3		
26		805704	SPARE FUSE	1	(15 AMP)	
26		805703	SPARE FUSE	1	(10 AMP)	
27		805439T 3	ELECTRICAL COVER	1		
28		807057	RELAY-FUEL PUMP/IGNITION SY	2		