



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	806744A	2 WIRING HARNESS	1		
2		26079A	2 PLATE ASSEMBLY	1		
3	10	15001	SCREW	4		
4		805468T	MOUNTING BRACKET	1		
5		815425	OIL PRESSURE SENDER	1		
5		37293	OIL PRESSURE SENDER (DUAL)	OPT		7
6		97257A	1 WATER TEMPERATURE SENDER	1		
6		49734A	1 WATER TEMPERATURE SENDER	OPT		7
7	13	26996	LOCKWASHER	2		
8	11	68219	NUT	2		
9	22	48556	BUSHING	1		
10	22	42554	NIPPLE	1		
11	22	46932	ELBOW	1		
12		805368T	MOUNTING BRACKET	1		
13	88	806950	CIRCUIT BREAKER (50 AMP)	1		
14	10	68513	SCREW	2		
15	13	26996	LOCKWASHER	2		
16	10	57583	SCREW (7/8 IN.)	2		
17	89	96158	STARTER SOLENOID	1		
18	10	805564	SCREW	2		
19	13	26992	LOCKWASHER (1/4)	2		
20	11	94330	NUT (1/4-20)	2		
21	13	26996	LOCKWASHER (#10)	2		
22	11	68219	NUT (10-32)	2		
23	85	97861	INSULATOR	1		
24	16	805459	STUD	1		
25	11	46438	NUT	1		
26	10	805565	SCREW	1		
27		806735T	BRACKET	1		
28	10	806834	SCREW (FLATHEAD)	1		
29	10	806835	SCREW	1		
30		806959T	4 IGNITION CONTROL MODULE (7.5)	1		
28		806960T	4 IGNITION CONTROL MODULE (7.5)	1		
28		806745T	5 IGNITION CONTROL MODULE (4.5)	1		
31	10	806826	SCREW	2		
32		805443T	KNOCK CONTROL MODULE	1		
33	10	806827	SCREW	2		
34		805544T	KNOCK SENSOR	1		