



1690

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	806964A 3	STARTER ASSEMBLY	1		
2	10	861788	SCREW, (M10 x 1.5), Special	2		
3	11	806949	NUT, (M8-1.5)	1		
4	13	40024 7	LOCKWASHER, (M8)	1		
5	11	40021 1	NUT, (M5)	1		
6	13	26996	LOCKWASHER, (#10)	1		
7	88	79023A91	FUSE ASSEMBLY, 90 Ampere	1		
8	11	826711 9	NUT, (.250-28)	1		
9	85	79695	BOOT, Insulator - Black	1		
10		863077I	ALTERNATOR ASSEMBLY, Black	1		
11	10	824459110	SCREW, (M8 x 110)	1		
12	11	40136 8	NUT, (M8)	1		
13		863337T	BRACKET, Alternator	1		
14	10	40108120	SCREW, (M10 x 120)	1		
15		862353A 1	ADJUSTMENT ASSEMBLY, Belt	1		
16		NSS	NOT SOLD SEPARATE, SCREW	1		
17	11	863409	NUT, (M10), Jam	1		
18	10	40011151	SCREW, (M8 x 35), Flange	1		
19	10	40108 35	SCREW, (M10 x 35)	1		
20	11	40021 2	NUT, (M6)	2		
21	57	863876 1	BELT, Serpentine	1		