



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	807321A	2 WIRING HARNESS	1		1
2	22	805328	1 ELBOW	1		
3		815425	1 OIL PRESSURE SENDER	1		
3		37293	1 OIL PRESSURE SENDER	OPT	(DUAL STATION)	5
4		97257A	1 WATER TEMPERATURE SENDER	1		
4		49734A	1 WATER TEMPERATURE SENDER	OPT	(DUAL STATION)	5
5	13	26996	2 LOCKWASHER	2		
6	11	68219	2 NUT	2		
7		805368T	1 MOUNTING BRACKET	1		
8	88	806950	1 CIRCUIT BREAKER (50 AMP)	1		
9	10	57583	2 SCREW (3/8 IN.)	2		
10	89	96158	1 STARTER SOLENOID	1		
11	10	805564	3 SCREW	3		
12	13	26992	2 LOCKWASHER (1/4)	2		
13	11	94330	2 NUT (1/4-20)	2		
14	13	26996	2 LOCKWASHER (#10)	2		
15	11	68219	2 NUT (10-32)	2		
16	85	97861	1 INSULATOR	1		
17		806735T	1 BRACKET	1		1
18	10	806834	1 SCREW	1	(FLATHEAD)	
19	10	806835	1 SCREW	1		
20		807645T	3 ICM MODULE	1		
21	10	806826	2 SCREW	2		