



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		807323A 5	ELECTRICAL BOX	1		
2		806762A 1	VELCRO KIT	1		
3		806611T	KNOCK MODULE	1		
4	11	64015	NUT	1		
5	89	96054	STARTER SOLENOID	1		
6	13	26395	LOCKWASHER (#8)	2		
7	11	26419	NUT (8-32)	2		
8	13	26392	LOCKWASHER (1/4")	2		
9	11	94330	NUT (1/4-20)	2		
10	12	35462	WASHER	2		
11	11	64015	NUT	2		
12	85	97861	INSULATOR	1		
13	88	11178	CIRCUIT BREAKER	1		
14	10	45862	SCREW	2		
15	11	61356	NUT	2		
16	13	26396	LOCKWASHER	2		
17	11	68219	NUT	2		
18		805615A 2	THUMB SCREW	1		
19	10	24323	SCREW	3	ALPHA ENGINES	
20	23	806981	SPACER	3	ALPHA ENGINES	
20	23	92152	SPACER	3	BRAVO ENGINES	
21	12	35462	WASHER	3		
22	11	64015	NUT	3		
23		807650T 1	ECM MODULE	1	5.7L ALPHA/BRAVO	
23		806720T 5	ECM MODULE	1	5.7LX ALPHA/BRAVO	
24	10	76596	SCREW	4		
25	12	20533	WASHER	4		
26	11	805562	NUT	3		
27		805704	SPARE FUSE	1	(15 AMP)	
27		805703	SPARE FUSE	1	(10 AMP)	
28		805439T 3	ELECTRICAL COVER	1		
29		807057	RELAY-FUEL PUMP	1		
29		807057	RELAY-IGNITION SYSTEM	1		