



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	14338A	5 HARNESS ASSEMBLY-Wiring	1		
2		26079A	2 PLATE KIT	1		
3	10	15001	SCREW (#8-16 x .875)	4		
4		816470	3 BRACKET-Electrical Mount	1		
5	10	37612	SCREW (.375-16 x 1.250)	3		
6	13	35048	LOCKWASHER (.375)	3		
7	23	90523	SPACER	3		
8	88	11178	BREAKER-Circuit (50 AMP)	1		
9	13	26996	LOCKWASHER (#10)	2		
10	11	68219	NUT (#10-32)	2		
11	10	45862	SCREW (#10-32 x .875)	2		
12	11	61356	NUT (#10-32)	2		
13	89	96054	SOLENOID-Starter	1		
14	10	98253	SCREW (.250-20 x .500)	2		
15	84	79139A	16 CABLE ASSEMBLY (RED) (35.500)	1		1
16	13	26992	LOCKWASHER (.250)	2		
17	11	94330	NUT (.250-20)	2		
18	13	26995	LOCKWASHER (#8)	2		
19	11	26419	NUT (#8-32)	2		
20		13611	SENDER-Oil Temperature	1		
21		97257A	1 SENDER-Water Temperature	1		
21		49734A	1 SENDER-Water Temperature (Dual)	OPT		5
22		815425	SENDER-Oil Pressure	1		
22		37293	SENDER-Oil Pressure (Dual)	OPT		5
23	13	26996	LOCKWASHER (#10)	3		
24	11	45076	NUT (#10-32)	3		
25	22	64013	REDUCER	1		
26	32	77690	WRAPPING	1		
27		17316A	2 IGNITION KIT	1		
28	10	49668	SCREW (.250-20 x .750)	4		
29	13	21272	LOCKWASHER (.250 Internal)	4		
30		816469	COIL	1		
31	10	49668	SCREW (.250-20 x .750)	2		
32	12	29245	WASHER	2		
33	11	56374	NUT (.250-20)	2		
34	11	68219	NUT (#10-32)	2		
35	13	26996	LOCKWASHER (#10)	2		
36	22	36492	BUSHING-Reducer	1		