



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	50	806964A 3	STARTER ASSEMBLY	1	(SEE PARTS BREAKDOWN)	
2	10	805343 2	SCREW-Special	2		
3	11	40021 1	NUT (5M)	1		
4	85	79695	BOOT-Insulator	1		
5	11	40063 5	NUT (8M)	1		
6	15	817272 1	SHIM-Special	1		
7		848129	LIFTING EYE	1		
8	10	90084	SCREW (.437-14 x 1.500)	1		
9	10	825427	SCREW (.437-14 x 1.250)	2		
10	12	45176	WASHER	3		
11	13	26996	LOCKWASHER (#10)	1		
12		817119 1	ALTERNATOR ASSEMBLY	1	(SEE PARTS BREAKDOWN)	
13	13	26992	LOCKWASHER (.250)	1		
14	11	56374	NUT (.250-20)	1		
15	12	96457	WASHER	1		
16	13	26996	LOCKWASHER (#10)	1		
17	11	79989	NUT (#10-24)	1		
18		85013T	BRACE-Alternator Adjusting	1		
19	12	45176	WASHER	1		
20	10	99204	SCREW (.437-14 x 1.00)	1		
21	12	26168	WASHER	1		
22	10	29198	SCREW & LOCKWASHER (.312-14)	1		
23	23	33186	BUSHING	1		
24	12	20553	WASHER	3		
25	10	48308	SCREW (.375-24 x 3.750)	1		
26		57908 11	SLEEVE-Alternator Lead	1		
27		807972 3	BRACKET-Alternator Mount	1		
28	11	23161	NUT (.375-24)	1		
29	54	848130	CLIP-Hose-Circulating Pump	1		