



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	807151A 9	PUMP ASSEMBLY-SEAWATER	1		
2	46	807151A14	BODY/IMPELLER KIT-WATER F	1		
3	25	33465	O-RING	1		
4	10	74822	SCREW (5/16-18 X 2-5/8 IN.)	5		
5	12	814806	WASHER	5		
6	47	59362T 1	IMPELLER	1		
7	25	94288	QUAD RING	1		
8		94576	PLATE-WEAR (INNER)	1		
9	46	94913A 5	HOUSING ASSEMBLY	1		
10	26	90562	SEAL-OIL	2		
11	30	72961	BEARING-BALL	2		
12		59501A 1	SHAFT	1		
13	53	23720	RING-SNAP	1		
14	26	72785	SEAL-OIL	1		
15		861579	PULLEY	1		
16		861087T	BRACKET	1		
17	16	806591	STUD-ALTERNATOR & SEAWATE	1		
18	10	17965	SCREW (7/16-14 X 3/4 IN.)	1		
19	13	40024 7	LOCKWASHER (5/16 IN.)	4		
20	11	21908	NUT (5/16-18)	4		
21		861530	BRACE	1		
22	12	814806	WASHER	2		
23	12	27345	WASHER	1		
24	11	22024	NUT (7/16-20)	1		