



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	84	806968A 2	WIRING HARNESS	1		
2	54	806616	CLAMP	1		
3	10	92913	SCREW	1		
4	13	32993	LOCKWASHER	1		
5		815425	OIL PRESSURE SENDER	1		
5		37293	OIL PRESSURE SENDER (DUAL)	OPT.		
6		97257A 1	WATER TEMPERATURE SENDER	OPT.		
6		49734A 1	WATER TEMPERATURE SENDER	OPT.		
7	13	26996	LOCKWASHER	2		
8	11	68219	NUT	2		
9	22	48556	BUSHING	1		
10	22	42554	NIPPLE	1		
11	22	46932	ELBOW	1		
12		805368T	MOUNTING BRACKET	1		
13	88	806950	CIRCUIT BREAKER (50AMP)	1		
14	10	57583	SCREW (7/8")	2		
15	89	96158	STARTER SOLENOID	1		
16	10	805564	SCREW	2		
17	13	26992	LOCKWASHER (1/4)	2		
18	11	94330	NUT (1/4-20)	2		
19	13	26996	LOCKWASHER (#10)	2		
20	11	68219	NUT (10-32)	2		
21	85	97861	INSULATOR	1		
22	23	99299	SPACER	1		
25		806735T	BRACKET	1		
26	10	806834	SCREW (FLATHEAD)	1		
27	10	806835	SCREW	1		
28		D806961T2	IGNITION CONTROL MODULE	1		
29	10	806826	SCREW	2		
30		805443T	KNOCK CONTROL MODULE	1		
31	10	806827	SCREW	2		
32		805544T	KNOCK SENSOR	1		