



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		806235A 1	HOUSING ASSEMBLY-Thermostat	1		
2	22	32803	PLUG-Pipe (3/8)	2		
3	27	806871	GASKET-Thermostat	1		22
4	27	53045 1	GASKET-Thermostat Housing	1		22
5		807252 2	THERMOSTAT	1		
6	23	806922	SLEEVE	1		
7	10	98794	SCREW (3/8-16 x 1 in.)	2		
8	32	807407	HOSE-Thermostat Housing to Engi	1		
9	32	808052	HOSE-Engine Oil Cooler to P/S Oil	1		
10	32	807404	HOSE-P/S Oil Cooler to Seawater F	1		
11	32	17435 79	HOSE-Seawater Pump to Drive Uni	1		
12	54	815504222	CLAMP	8		
13	32	89718 1	HOSE-Thermostat Housing to Wate	1		
14	54	815504232	CLAMP	2		
15	32	89749 1	HOSE-Thermostat Housing to Port I	1		
16	32	807201	HOSE-Thermostat Housing to Start	1		
17	54	815504220	CLAMP	4		
18	54	806616	CLAMP	1		
19		77054	STA-STRAP (14.50 in.)	1		
20		99356A 2	COOLER-Power Steering Oil	1		
21		807402T	BRACKET-Oil Cooler	1		
22		807445T	CLAMP	1		
23	12	35462	WASHER	1		
24	11	72008	NUT (.250-20)	1		
25	10	86750	SCREW (.312-18 x 5/8 in.)	1		
26	13	39107	LOCKWASHER (5/16 in.)	1		
-	27	805396A95	GASKET SET-Overhaul	1		