



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	87	815425T	SENDER ASSEMBLY, Oil Pressure	1		
2		881879A 6	SENSOR, (0 - 100 PSI), Oil Pressur	1		
3		805218T	SENSOR, Coolant	1		
4		806490T	SENDER, Coolant Temperature	1		
5		865155T01	MODULE ASSEMBLY, ECM	1	(350 MPI) SN# 0w/395629 & Belc	
5		865155T03	MODULE ASSEMBLY, ECM	1	(350 MPI) SN# 0w/395630 & Up	
5		865156T01	MODULE ASSEMBLY, ECM	1	(6.2L MPI) SN# 0w/395624 & Belc	
5		865156T04	MODULE ASSEMBLY, ECM	1	(6.2L MPI) SN# 0w/395625 & Up	
6	10	821300 25	SCREW, (M6 x 25)	3		
7	12	65567	WASHER, (.265 x .750 x .048)	3		
8	25	834985	GROMMET	3		
9	23	856954	BUSHING	3		
10		865218T	BRACKET , ECM Mounting	1		
11	10	860008	SCREW, Torx (.250-20 x .625)	2		
12	84	865245T02	WIRING HARNESS	1		
13	54	865205	CLIP, Relay Mounting	2		
14	54	879962	CLIP, Fuse Block Mounting	1		
15		831960	COVER, Fuse	1		
16		865202T	RELAY	2		
17	88	832969 20	FUSE, Yellow - 20 Ampere	3		
18		865220T	BRACKET, Relay Mounting	1		
19	88	806950	CIRCUIT BREAKER, (50 Ampere)	1		
20	13	26996	LOCKWASHER, (#10)	2		
21	10	68513	SCREW, (#10-32 x .375)	2		
22	10	57583	SCREW, (#8-32 x .375)	2		
23	89	96158T	SOLENOID, Starter	1		
24	13	26992	LOCKWASHER, (.250)	2		
25	11	26419	NUT, (#8-32)	2		
26	10	41508	SCREW, (.250-20 x .500)	2		
27	13	26995	LOCKWASHER, (#8)	2		
28	11	26419	NUT, (#8-32)	2		
29	85	97861	INSULATOR, Starter Solenoid	1		
30		816492A 6	ALARM KIT	1		
31	10	98261	SCREW, (.375-16 x .750)	3		
32	84	861940T 1	HARNESS, Neutral Safety Switch	1		
33	84	862021T 1	HARNESS, Transmission Temperat	1		
34	13	26992	LOCKWASHER, (.250)	2		
35		878187	SENSOR ASSEMBLY, Knock	11		
36	84	865145T 02	HARNESS, Wiring	1	(In Gear Indicator)	
37		891735	CAP, Weather Proof, 10 Pin Harne:	1		
38	22	864659	FITTING	1		