



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		76395A	HYDRAULIC PUMP ASSEMBLY (S	1		
2	25	21720	"O" RING, HYDRAULIC PUMP T	4		
3	10	28634	SCREW, FILLER - HYDRAULIC I	1		
4	12	20260	WASHER, SEALING - HYDRAULI	1		
5	10	38257	SCREW, VENT - HYDRAULIC PI	1		
7		32979	BATTERY LEAD (POSITIVE)	1		
8		32988	BATTERY LEAD (NEGATIVE)	1		
9		45336	PLATE, MANIFOLD	1		
10		45197A	CONTROL VALVE ASSEMBLY	1		
10	25	21720	"O" RING, PUMP TO MANIFOLD	4		
11	25	45254	"O" RING, CONTROL VALVE TC	1		
12	25	21720	"O" RING, CONTROL VALVE TC	1		
13	25	45253	"O" RING, CONTROL VALVE TC	2		
14	10	56500	SCREW, VALVE AND MANIFOLD	4		
15	13	26992	LOCKWASHER, CONTROL VALVE	4		
17	22	46008	PLUG, CONTROL VALVE (1/2-20"	2		
18	84	74023	CONNECTOR AND HARNESS	1		
22		45377	BRACKET, MOUNTING - HYDRAL	2		
23	10	24234	SCREW, MOUNTING BRACKET T	4		
24	13	39107	LOCKWASHER, MOUNTING BRAC	4		
25	11	21908	NUT, MOUNTING BRACKET SCR	4		
26	10	68298	BOLT, HYDRAULIC PUMP TO BO	2		
27	11	68411	NUT, HYDRAULIC PUMP BOLT	2		
28	89	68258	STARTER SOLENOID	2		
29	13	26996	LOCKWASHER, STARTER SOLEI	4		
30	11	68219	NUT, STARTER SOLENOID TERM	4		
31	13	26993	LOCKWASHER, STARTER SOLEI	4		
32	11	68292	NUT, STARTER SOLENOID TERM	4		
33		46265	BOOT, RUBBER - STARTER SOLI	4		
34		74407	BRACKET, MOUNTING - STARTE	1		
35	10	21140	SCREW, MOUNTING BRACKET T	2		
36	13	26992	LOCKWASHER, MOUNTING BRA	2		
37	11	24656	NUT, MOUNTING BRACKET TO F	1		
38		26901	BUMPER, RUBBER - SOLENOID E	1		
39		55991	BATTERY LEAD (POSITIVE)	1		
39		55992	BATTERY LEAD (NEGATIVE)	1		
40		74406	BRACKET, MOUNTING - STARTE	1		
41	10	69028	SCREW, MOUNTING BRACKET T	2		
42	13	26992	LOCKWASHER, MOUNTING BRA	2		
43	10	34290	SCREW, STARTER SOLENOID TI	2		
44	12	26992	LOCKWASHER, STARTER SOLEI	2		