



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1623	6048A 7	GEAR HOUSING ASSEMBLY, CO	1	
-	1623	6053A13	GEAR HOUSING ASSEMBLY, CO	1	
1	1623	6048A 3	GEAR HOUSING ASSEMBLY (M	1	
1	1623	6053A 5	GEAR HOUSING ASSEMBLY (M	1	
51		54346	CAM, SHIFT	1	
52		30625	FOLLOWER, CAM	1	
53		30624	SLIDE, CROSS PIN	1	
54	24	30622	SPRING, COMPRESSION - CAM	1	
55	15	30923A 1	SHIM, BEARING OUTER RACE	AR	
56	31	30894A 1	TAPERED ROLLER BEARING A	1	
57	31	30895	BEARING, ROLLER - FORWARD	1	
58	43	75314	FORWARD GEAR ASSEMBLY	1	
59	52	34239	RATCHET, SLIDING CLUTCH	1	
60	17	30632	PIN, CROSS - RATCHET TO PR	1	
61	24	30893	SPRING, RETAINING - CROSS	1	
62	44	52542	SHAFT, PROPELLER	1	
63	43	75315	REVERSE GEAR ASSEMBLY	1	
65	12	71143A 1	WASHER, THRUST - BEARING C	1	
66	30	31265	BEARING, BALL - REVERSE GE	1	
67	25	29976	"O" RING, BEARING CARRIER	1	4
68		73800A 1	BEARING CARRIER ASSEMBLY	1	
68		52132A 1	BEARING CARRIER ASSEMBLY	1	
69	31	30956	BEARING, ROLLER - BEARIN	1	
70	26	76868	OIL SEAL, BEARING CARRIER	2	
--	25	32546	"O" RING, BEARING CARRIER	1	4
71	28	30281	KEY, LOCATING - BEARING CA	1	
72	14	52700	TAB WASHER, GEAR HOUSING	1	
73		52699	COVER, GEAR HOUSING	1	
74		31640A 1	TRIM TAB, GEAR HOUSING	1	
75	10	66024	SCREW, TRIM TAB TO GEAR H	1	
76	12	45176	WASHER, GEAR HOUSING TO D	2	
77	11	34933	NUT, GEAR HOUSING TO DRIVE	2	
78	10	65210	SCREW, GEAR HOUSING TO DR	1	
79		65091	THRUST HUB	1	
81	12	31211	WASHER, SPLINED - PROPELLER	1	
82	14	31210	TAB WASHER, PROPELLER NUT	1	
83	11	52707	NUT, PROPELLER	1	