



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
--	1655	7333A24	GEAR HOUSING ASSEMBLY, CO	1		
1	1655	7333A23	GEAR HOUSING ASSEMBLY	1		
1A	22	85822A 1	CONNECTOR ASSEMBLY, SP	1		
2	17	46912	DOWEL PIN, GEAR HOUSING	2		
3	16	57921	STUD, GEAR HOUSING (4")	1		
4	16	57920	STUD, GEAR HOUSING (2-1/2")	2		
5	16	56297	STUD, WATER PUMP (3-3/8")	1		
6	16	69501	STUD, WATER PUMP (3-1/8")	2		
7	31	32898	ROLLER BEARING, DRIVE SH	1		
8	45	76036	DRIVE SHAFT	1		
9	43	68548	PINION GEAR, DRIVE SHAFT	1		
10	11	35921	NUT, PINION GEAR TO DRIVE	1		
11	23	70412	SPACER, BALL BEARING	1		
11	15	57007A 1	SHIM, BALL BEARING	AR		3
12	31	69220	ROLLER BEARING, DRIVE SHA	1		
14	27	33146	GASKET, WATER PUMP	1		2
15	25	33145	"O" RING, WATER PUMP	1		2
16	46	96146A 5	WATER PUMP BASE ASSEMBL	1		
17	26	94038	OIL SEAL, WATER PUMP	1		
18	26	79884	OIL SEAL, WATER PUMP	1		
19	17	35973	DOWEL PIN, WATER PUMP	AR		3
20	27	32433	GASKET, LOWER - WATER PUI	1		2
21		32435	FACE PLATE	1		
22	27	32434	GASKET, UPPER - FACE PLATE	1		2
23	46	96148A 1	WATER PUMP BODY ASSEMBL	1		
24		48752	INSERT, WATER PUMP	1		
26	26	38970	SEAL, RUBBER - WATER INLI	1		
27	47	89984	IMPELLER, WATER PUMP	1		
28	28	56654	KEY, IMPELLER DRIVE	1		
29	10	30720	SCREW, WATER PUMP (1/4-20)	AR		3
29	10	96411	SCREW, WATER PUMP (14-8 -	AR		3
30	13	26992	LOCKWASHER, WATER PUMP S	1		
31	12	29245	WASHER, WATER PUMP SCRE	3		
32	11	35888	NUT, WATER PUMP SCREW	2		
33	12	36001	WASHER, WATER PUMP STUC	1		
34	11	35814	NUT, WATER PUMP STUD	1		
35	25	30271	RING, RUBBER - DRIVE SHAFT	1		2
36	23	29804	SLEEVE, GUIDE - WATER INLE	1		
37		37641	SEAL, EXHAUST	1		
38		38051	PLATE, SUPPORT - EXHAUST	1		
39		76062A 1	SHAFT ASSEMBLY, SHIF	1		