

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
0	91	880118A 2	DDT CARTRIDGE	1	(ELECTRICAL/IGNITION)	
0	84	822560A 5	EFI TEST HARNESS	1	(ELECTRICAL/IGNITION)	
0	91	52344	FLYWHEEL HOLDER	1		
0	91	849154T 1	FLYWHEEL PULLER	1		
0	84	825003A 1	HARNESS	1	(IGNITION)	
0	91	823686A 2	IGNITION DIAGNOSTIC UNIT	1	(ELECTRICAL/IGNITION)	
0	91	99750A 1	MULTI METER/DVA TESTER	1	(ELECTRICAL/IGNITION)	
0	91	52024A 1	REMOTE STARTER SWITCH	1	(ELECTRICAL/IGNITION)	
0	91	59339	SERVICE TACHOMETER	1	(ELECTRICAL/IGNITION)	
0	91	850439T 1	SPARK GAP TESTER-EIGHT CHA	1	(ELECTRICAL/IGNITION)	
0	91	63998A 1	SPARK GAP TESTER-SINGLE CH	1	(ELECTRICAL/IGNITION)	
0	91	850439T	SPARK TESTER	1	(IGNITION)	
0	91	825824A 2	TACH INTERFACE MODULE	1	(ELECTRICAL/IGNITION)	
0	91	99379	TIMING LIGHT	1	(ELECTRICAL/IGNITION)	
0	91	11230 1	ALIGNMENT TOOL	1	(TRIM/TILT SYSTEM)	
0	91	99750A 1	MULTI-METER DVA TESTER	1	(TRIM/TILT SYSTEM)	
0	91	52915A 6	POWER TRIM TEST GAUGE KIT	1		
0	91	74951	SPANNER WRENCH	1	(TRIM/TILT SYSTEM)	
0	91	63209	TORCH LAMP	1	(TRIM/TILT SYSTEM)	
0	91	44487T 1	TRIM ROD GUIDE REMOVER TO	1	(TRIM/TILT SYSTEM)	
0	91	44486A 1	TRIM ROD REMOVAL TOOL	1	(TRIM/TILT SYSTEM)	
0	91	55319	DRIVER HEAD	1	(POWERHEAD)	
0	91	90455T	LIFTING EYE	1	(POWERHEAD)	
0	91	77109A 3	LOCK RING INSTALLATION TOOL	1	(POWERHEAD)	
0	91	52952T 1	LOCK RING REMOVAL TOOL	1	(POWERHEAD)	
0	91	24697	PISTON RING EXPANDER	1	(POWERHEAD)	
0	91	92973A 1	PISTON PIN TOOL	1	(POWERHEAD)	
0	91	30591T 1	POWERHEAD STAND	1	(POWERHEAD)	
0	91	24161	PROTECTOR CAP-FLYWHEEL	1	(POWERHEAD)	
0	91	818773T	RING COMPRESSOR	1	(2.5L)(POWERHEAD)	
0	91	66274	TORQUE WRENCH (2-150 lb-in)	1	(POWERHEAD)	
0	91	37241	UNIVERSAL PULLER PLATE	1	(POWERHEAD)	
0	91	881834A 1	DUAL FUEL/AIR PRESSURE GAL	1	(DFI)	
0	91	851980 2	SEAL/TEFLON RING INSTALLATI	1	(DFI)	
0	91	851980 3	SEAL/TEFLON RING SIZING TOC	1	(DFI)	
0	91	16850A 7	SINGLE FUEL/AIR PRESSURE Ga	1	(DFI)	
0	91	78473	BACKLASH INDICATOR TOOL	1	(GEAR HOUSING)	
0	91	19660 1	BACKLASH INDICATOR UPDATE	1	(GEAR HOUSING)	
0	91	31106T	BEARING DRIVER CUP	1	(GEAR HOUSING)	
0	91	87120T	BEARING DRIVER CUP	1	(GEAR HOUSING)	
0	91	18601	BEARING INSTALLATION TOOL	1	(GEAR HOUSING)	

NO IMAGE