



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		43429	PLATE, IGNITION	1		
2	332	7778A	SWITCH BOX	2		
3	10	13669	SCREW, SWITCH BOX TO IGNITI	2	(2-1/2")	
4	23	94453	BUSHING, SWITCH BOX SCREW	2		
5	84	62310A	CABLE ASSEMBLY, SWITCH BOX	1		
6	11	45076	NUT, SWITCH BOX TERMINAL	20		
7	84	60871A	WIRE, SWITCH BOX (6")	2		
8	10	62568	SCREW, WIRE ATTACHING	3		
9	84	65999A	CABLE ASSEMBLY, BLACK	1		
10	10	69092	SCREW, IGNITION PLATE	3	(1-1/4")	
11	13	26393	LOCKWASHER, IGNITION PLATE	3		
12	12	36042	WASHER, IGNITION PLATE SCRE	6		
13	12	67264	WASHER, IGNITION PLATE SCRE	6		
14	23	67268	BUSHING, IGNITION PLATE SCRI	3		
15	87	33386A	MERCURY SWITCH	1		
16	10	38055	SCREW, MERCURY SWITCH TO	1	(5/8")	
17	11	45076	NUT, MERCURY SWITCH TERMI	1		
18	10	87926	SCREW, LEAD ATTACHING	1	(1/2")	
19	84	88439A	BATTERY CABLE, POSITIVE (ME	1		
19	84	88439A	BATTERY CABLE, NEGATIVE (ME	1		
20	84	96220A	HARNESS, ENGINE	1		
21	88	79091	FUSE	1		
22	84	95084A	WIRE ASSEMBLY, FUSE	1		
23		13473	FUSE HOLDER	1		
24	54	90077	STA-STRAP, HARNESS AND CAB	AR		6
25	89	15857	STARTER SOLENOID	1		
26	11	45076	NUT, SOLENOID TERMINALS (10	2		
27	13	53166	LOCKWASHER, SOLENOID TERM	2		
28	11	68292	NUT, SOLENOID TERMINALS (5/	2		
29	10	31716	SCREW, SOLENOID TO IGNITION	2	(5/8")	
30	13	26392	LOCKWASHER	2	SOLENOID TO IGNITION PLATE	
31	84	65999A	CABLE ASSEMBLY, UPPER MOUI	1		
32	85	78866	INSULATOR, SOLENOID	1		
33	54	47483	"J" CLIP	2		