

NOTE: TO INSURE ORDERING THE CORRECT REPLACEMENT GEAR HOUSING COMPONENTS, IDENTIFY YOUR GEAR HOUSING BY USING THE DIAGRAM ABOVE. IF YOUR GEAR HOUSING (DESIGN I - 3 JAW REVERSE CLUTCH) HAS A STRAIGHT MACHINED EDGE FOR TRIM TAB SCREW MOUNTING (A), ORDER FROM GEAR HOUSING BREAKDOWN PAGES (3 JAW REVERSE CLUTCH). IF YOUR GEAR HOUSING (DESIGN II - 6 JAW REVERSE CLUTCH) HAS AN ANGLED MACHINED EDGE (B) ORDER FROM GEAR HOUSING BREAKDOWN PAGES (6 JAW REVERSE

CLUTCH).