



A - BEFORE ORDERING REPAIR KITS, LOOK AT WEBER NUMBER (EXAMPLE: 97765B) AT LOCATION SHOWN. ONLY ORDER KITS THAT FIT CARBURETOR THAT YOU ARE REPAIRING.

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		823728	OVERHAUL KIT	1	(9600)	
1		809071	OVERHAUL KIT	1	(9662)-SWISS EMISSIONS (BSO	
2	27	809077	GASKET	1		
3		811533	FITTING KIT-Inlet	1		
4		823727	NEEDLE & SEAT KIT	2		
5		811831	METERING ROD KIT	1	(9600)	
5		809073	METERING ROD KIT	1	(9662)-SWISS EMISSIONS (BSO	
6		811536	FLOAT KIT	2		
7		811537	PUMP PLUNGER KIT	1		
8		811538	CHOKE PULL DOWN KIT (Automa	1		
9		811539	SCREW KIT-Idle Mixture	2	(9600)	
10		809072	SCREW KIT-Idle Mixture	1	(9662)-SWISS EMISSIONS (BSO	
11		823724	METERING JET-Primary	2	(9600)	
11		809075	METERING JET-Primary	2	(9662)-SWISS EMISSIONS (BSO	
12		823724	METERING JET-Secondary	2	(9600)	
12		823721	METERING JET-Secondary	2	(9662)-SWISS EMISS. (BSO1 & S	
13	32	14301 65	VACUUM HOSE (Automatic Choke	1		