



A = BEFORE ORDERING REPAIR KITS, LOOK AT WEBER NUMBER (EXAMPLE: 9776SB) AT LOCATION SHOWN. ONLY ORDER KITS THAT FIT CARBURETOR THAT YOU ARE REPAIRING.

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		835076	OVERHAUL KIT	1	(9666)	
1		852947	OVERHAUL KIT	1	(9667) SWISS EMISSIONS (BS01	
2	27	809077	GASKET	1		
3		811533	INLET FITTING KIT	1		
4		823727	INLET NEEDLE & SEAT KIT	2	(9666)	
4		811534	INLET NEEDLE & SEAT KIT	2	(9667) SWISS EMISS. (BS01 & S	
5		835077	METERING ROD KIT	1		
6		811536	FLOAT KIT	2		
7		811537	PUMP PLUNGER KIT	1		
8		811539	IDLE MIXTURE SCREW KIT	2	(9666)	
8		809072	IDLE MIXTURE SCREW KIT	2	(9667) SWISS EMISS. (BS01 & S	
9		835078	PRIMARY METERING JET	2	(9666)	
9		803023	PRIMARY METERING JET	2	(9667) SWISS EMISS. (BS01 & S	
10		823724	SECONDARY METERING JET	2	(9666)	
10		823723	SECONDARY METERING JET	2	(9667) SWISS EMIS. (BS01 & SAV	
11		809066	ELECTRIC CHOKE REPAIR KIT	1		
12		809095	ELECTRIC CHOKE RETAINER KIT	1		
13	84	809471A	WIRE KIT	1		