



A = BEFORE ORDERING REPAIR KITS, LOOK AT WEBER NUMBER (EXAMPLE: 9776SB) AT LOCATION SHOWN.  
 ONLY ORDER KITS THAT FIT CARBURETOR THAT YOU ARE REPAIRING.

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		809064	OVERHAUL KIT	1	(9781)	
1		852947	OVERHAUL KIT	1	(9668) -SWISS EMISSIONS (BSO	
2	27	809077	GASKET	1		
3		811533	INLET FITTING KIT	1		
4		811534	INLET NEEDLE AND SEAT KIT	2		
5		809768	METERING ROD KIT	1	(9781)	
5		852948	METERING ROD KIT	1	(9668) -SWISS EMISSIONS (BSO	
6		811536	FLOAT KIT	2		
7		811537	PUMP PLUNGER KIT	1		
8		811538	CHOKE PULL DOWN KIT	1	(AUTOMATIC CHOKE)	
9		811539	IDLE MIXTURE SCREW KIT	2	(9781)	
10		809072	IDLE MIXTURE SCREW KIT	1	(9668) -SWISS EMISS. (BSO1 AN	
11		809769	PRIMARY METERING JET	2	(9781)	
11		809076	PRIMARY METERING JET	2	(9668) -SWISS EMISS. (BSO1 AN	
12		811657	SECONDARY METERING JET	2	(9781)	
12		823723	SECONDARY METERING JET	2	(9668) -SWISS EMIS. (BSO1 AND :	
13	32	14301 65	VACUUM HOSE	1	(AUTOMATIC CHOKE)	
14		809066	ELECTRIC CHOKE REPAIR KIT	1	(ELECTRIC CHOKE)	
15		809095	ELECTRIC CHOKE RETAINER KIT	1	(ELECTRIC CHOKE)	
16	84	809471A 1	WIRE KIT	1	(ELECTRIC CHOKE)	