



A = BEFORE ORDERING REPAIR KITS, LOOK AT WEBER NUMBER (EXAMPLE: 9776SB) AT LOCATION SHOWN. ONLY ORDER KITS THAT FIT CARBURETOR THAT YOU ARE REPAIRING.

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		809064	OVERHAUL KIT	1		
2	27	809077	GASKET	1		
3		811533	INLET FITTING KIT	1		
4		811534	INLET NEEDLE & SEAT KIT	2		
5		809768	METERING ROD KIT	1		
6		811536	FLOAT KIT	2		
7		811537	PUMP PLUNGER KIT	1		
8		811539	IDLE MIXTURE SCREW KIT	2		
9		809769	PRIMARY METERING JET	2		
10		811657	SECONDARY METERING JET	2		
11		809066	ELECTRIC CHOKE REPAIR KIT	1	(ELECTRIC CHOKE)	
12		809095	ELECTRIC CHOKE RETAINER KIT	1	(ELECTRIC CHOKE)	
13	84	809471A 1	WIRE KIT	1	(ELECTRIC CHOKE)	