



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		32683	COVER, INTAKE MANIFOLD	1		
2	27	34047	GASKET, INTAKE MANIFOLD COV	1		
3	22	36382	PLUG, PIPE - INTAKE MANIFOLD	1		
4	10	35581	SCREW, INTAKE COVER TO EXH	4	SERIAL 01604625-01731503	
5	10	35582	SCREW, INTAKE COVER TO EXH	8	SERIAL 01604625-01731503	
6	13	26992	LOCKWASHER, INTAKE COVER	12	SERIAL 01604625-01731503	
4	10	38326	SCREW, INTAKE COVER TO EXH	4	SERIAL 01731504-09999999	
5	10	38327	SCREW, INTAKE COVER TO EXH	8	SERIAL 01731504-09999999	
7		35138	BODY, EXHAUST MANIFOLD	1		
8	10	21077	SCREW, EXHAUST MANIFOLD B	2		
9	16	34612	STUD, EXHAUST MANIFOLD BOI	4		
10	13	37459	LOCKWASHER, EXHAUST MANIF	6		
11	12	20553	WASHER, EXHAUST MANIFOLD	6		
12	11	20087	NUT, EXHAUST MANIFOLD BOD	4		
13	27	32816	GASKET, EXHAUST MANIFOLD B	1		
14		32797	COVER, CHOKE OVEN - EXHAUS	1		
15	27	32815	GASKET, CHOKE OVEN COVER	1		
16	10	28192	SCREW, CHOKE OVEN COVER T	2		
17	22	21373	CONNECTOR, CHOKE OVEN COV	1		
18		35149	ELBOW, WATER OUTLET - EXHA	1		
19	27	35150	GASKET, EXHAUST MANIFOLD E	1		
20	10	35388	SCREW, WATER OUTLET ELBO	5		
21	32	33484	HOSE, WATER OUTLET ELBOW	1		
22	54	32781	CLAMP, HOSE TO WATER OUTL	2		
23		32877	COVER, WATER PUMP	1		
24	54	38426	CLAMP, WATER PUMP COVER T	1		
25	10	25299	SCREW, WATER PUMP FLANGE	1		
26	22	32715	ELBOW, WATER INLET HOSE - E	1		
27	32	32844	HOSE, WATER INLET - EXHAUS	1		
28	54	32779	CLAMP, HOSE TO EXHAUST MA	2		
29	27	35140	GASKET, INNER WATER JACKET	1		
30		35139	COVER, WATERJACKET - INNER	1		
31	27	35142	GASKET, OUTER COVER TO INN	1		
32		35141	COVER, WATER JACKET - OUTE	1		
33	10	35390	SCREW, OUTER AND INNER CO	22		
34	22	32802	PLUG, PIPE - OUTER WATER JA	1		
35	54	22740	CLIP, WIRING HARNESS TO OUT	1		
36	10	29240	SCREW, WIRING HARNESS CLIF	1		
37		22789	"D" WASHER, WIRING HARNESS	1		
35	54	28938	CLAMP, WIRING HARNESS TO O	1		
36	10	29021	SCREW, WIRING HARNESS CLAI	1		