



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		32484	HOUSING, FLYWHEEL USE THRI	1	SERIAL 00000000-01667230	
1A		35865A 2	FLYWHEEL HOUSING ASSEMBL	1	SERIAL 01667231-09999999	
2	23	35903	SPACER, FLYWHEEL HOUSING	2	SERIAL 01667231-09999999	
3		35864	COVER PLATE, FLYWHEEL HO	1	SERIAL 01667231-09999999	
4	10	20705	SCREW, COVER PLATE TO FLY	6	SERIAL 01667231-09999999	
5	11	29250	NUT, COVER PLATE SCREW	6	SERIAL 01667231-09999999	
6	54	34764	EYE, LIFTING - FLYWHEEL HOU	1		
7	10	26632	SCREW, FLYWHEEL HOUSING T	5	QUANTITY WAS 6 SERIAL 0000	
8	10	34613	SCREW, FLYWHEEL HOUSING T	1	SERIAL 01565958-01949901	
9	13	37459	LOCKWASHER, FLYWHEEL HOU	6	SERIAL 01565958-01949901	
10	11	32219	NUT, FLYWHEEL HOUSING SCR	1	SERIAL 01565958-01949901	
7	10	26632	SCREW, FLYWHEEL HOUSING T	4	SERIAL 01949902-09999999	
8	10	28464	SCREW, BRACKET AND FLYWHE	1	SERIAL 01949902-09999999	
8	10	45754	SCREW, BRACKET AND FLYWHE	1	SERIAL 01949902-09999999	
9	13	37459	LOCKWASHER, BRACKET AND F	6	SERIAL 01949902-09999999	
10	11	28517	NUT, BRACKET AND FLYWHEEL	1	SERIAL 01949902-09999999	
11		32786	TAB, WIRING HARNESS TO FLY	2	SERIAL 00000000-01949901	
12	54	24871	CLAMP, WIRING HARNESS TO FI	2	SERIAL 00000000-01565943	
12	54	22690	CLAMP, WIRING HARNESS TO FI	1	SERIAL 01565944-01949901	
12	54	22627	CLAMP, WIRING HARNESS TO FI	1	SERIAL 01565944-01949901	
13	10	20191	SCREW, WIRING HARNESS CLAI	2	SERIAL 00000000-01949901	
14	13	26395	LOCKWASHER, WIRING HARNE	2	SERIAL 00000000-01949901	
15		22789	"D" WASHER, WIRING HARNE	2	SERIAL 00000000-01949901	
16	11	26419	NUT, WIRING HARNESS CLAMP	2	SERIAL 00000000-01949901	
12	54	24871	CLAMP, WIRING HARNESS TO FI	1	SERIAL 01949902-09999999	
13	10	22028	SCREW, WIRING HARESS CLAM	1	SERIAL 01949902-09999999	
14	13	26396	LOCKWASHER, WIRING HARNE	1	SERIAL 01949902-09999999	
17		39974	CONNECTOR, HARNESS LEADS	2	SERIAL 01949902-09999999	
18	10	37892	SCREW, CONNECTOR TO FLYWI	2	SERIAL 01949902-09999999	
19		32692	MOUNT, FLYWHEEL HOUSING (L	2	SERIAL 00000000-01539608	
19		32832	MOUNT, FLYWHEEL HOUSING (L	1	SERIAL 01539309-09999999	
19		33149	MOUNT, FLYWHEEL HOUSING (F	1	SERIAL 01539309-09999999	
20	54	34764	EYE, LIFTING - CYLINDER BLOC	1		
21	10	27165	SCREW, LIFTING EYE TO CYLIN	1		
22	13	37459	LOCKWASHER, LIFTING EYE SC	1		
23	38	31042	SERIAL PLATE	1		
24	10	20314	SCREW, DRIVE - SERIAL PLATE	2		
25		32604A 2	BRACKET ASSEMBLY, FRONT MI	1	SERIAL 00000000-01667230	
26	12	32639	WASHER, FRONT MOUNTING I	1	SERIAL 00000000-01667230	
27	12	32552	WASHER, FRONT MOUNTING I	1	SERIAL 00000000-01667230	
28		22822	MOUNT, FRONT MOUNTING RI	1	SERIAL 00000000-01667230	