



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
35		34539	GAUGE ASSEMBLY,OIL LEVEL (D)	1	SERIAL 00000000-01946513	
36	32	34540	TUBE,OIL LEVEL GAUGE	1	SERIAL 00000000-01946513	
35		45490	GAUGE ASSEMBLY,OIL LEVEL(DI)	1	SERIAL 01946514-09999999	
36	32	45489	TUBE,OIL LEVEL GAUGE	1	SERIAL 01946514-09999999	
37		34489	COVER,PUSH ROD	1	SERIAL 00000000-01951139	
38	10	34470	SCREW,PUSH ROD COVER TO C	4	SERIAL 00000000-01951139	
39	25	25429	"O"RING,PUSH ROD COVER SCF	4	SERIAL 00000000-01951139	
37		39332A	COVER ASSEMBLY,PUSH ROD	1	SERIAL 01951140-09999999	
38	10	39783	SCREW,PUSH ROD COVER T	4	SERIAL 01951140-09999999	
40	27	34208	GASKET,PUSH ROD COVER	1		
41	54	53883	CLIP,WIRING HARNESS TO PUSI	1	SERIAL 02046625-09999999	
42	10	30663	SCREW,WIRING HARNESS CLIP	1	SERIAL 02046625-09999999	
43		22789	"D" WASHER,WIRING HARNESS	1	SERIAL 02046625-09999999	
44		36405	OIL PUMP ASSEMBLY	1		
	27	34460	GASKET,OIL PUMP COVER	1		
45	10	35339	SCREW,OIL PUMP TO CYLINDEF	2		
46	10	35366	SCREW, OIL PUMP SCREEN TO I	1		
47		37374	SCREEN ASSEMBLY,OIL PPUMP	1	SERIAL 00000000-02361801	
47		52146	SCREEN ASSEMBLY,OIL PUMP	1	SERIAL 02361802-09999999	
	10	46470	SCREW,OIL PUMPP CSCREEN SI	1	SERIAL 01951140-09999999	
		34541	SUPPORT, OIL PUMP	1		
48		32720	CONNECTOR, OIL FILTER TO CY	1		
49		54111	OIL FILTER ASSEMBLY	1		
50		35603	COVER ASSEMBLY, CRANKCASE	1	SERIAL 00000000-02361801	
51	26	34218	OIL SEAL,CRANKCASE COVEI	1	SERIAL 00000000-02361801	
52	27	34216	GASKET,CRANKCASE COVER	1	SERIAL 00000000-02361801	
53	10	34277	BOLT, CRANKCASE COVER TO C	8	SERIAL 00000000-02361801	
54		34234	OIL PAN ASSEMBLY	1	SERIAL 00000000-02361801	
55	27	34206	GASKET SET, OIL PAN	1	SERIAL 00000000-02361801	
56	10	34277	SCREW,OIL PAN TO CYLINDER E	18	SERIAL 00000000-02361801	
57	10	34500	SCREW,OIL PAN TO CYLINDER E	4	SERIAL 00000000-02361801	
58	10	34501	SCREW,DRAIN - OIL PAN	1	SERIAL 00000000-02361801	
59	27	34502	GASKET,OIL PAN DRAIN SCREW	1	SERIAL 00000000-02361801	
50		49951	COVER ASSEMBLY,CRANKCASE	1	SERIAL 02361802-09999999	
51	26	49952	OIL SEAL, CRANKCASE COVE	1	SERIAL 02361802-09999999	
52	27	49953	GASKET,CRANKCASE COVER	1	SERIAL 02361802-09999999	
53	10	34277	SCREW,CRANKCASE COVER TO	8	SERIAL 02361802-09999999	
54		52583	OIL PAN ASSEMBLY	1	SERIAL 02361802-09999999	
55	27	52144	GASKET SET, OIL PAN	1	SERIAL 02361802-09999999	
56	10	49950	SCREW,OIL PAN TO CYLINDER E	14	SERIAL 02361802-09999999	
57	10	34500	SCREW,OIL PAN TO CYLINDER E	4	SERIAL 02361802-09999999	