



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		62575	COVER, INTAKE MANIFOLD	1	
2	27	35898	GASKET, INTAKE MANIFOLD COV	1	2
3	22	36382	PLUG, PIPE - INTAKE MANIFOLD	1	
4	10	35390	SCREW, INTAKE MANIFOLD COV	4	
5	10	35388	SCREW, INTAKE MANIFOLD COV	8	
6	10	64969	SCREW, SET - THROTTLE STOP	1	
7	11	33122	NUT, SET SCREW	1	
8	27	52546	GASKET, EXHAUST MANIFOLD T	1	8,2
9		60372A 1	COVER, THERMOSTAT - WATER	1	
10	10	60374	SCREW, THERM. COVER TO W	2	
11	12	36533	WASHER, THERMOSTAT COVE	1	
12	32	47639	HOSE, WATER DISTRIBUTION B	1	
13	54	32880	CLAMP, HOSE TO WATER DIST.	2	
14		59078	THERMOSTAT	1	
15	27	47590	GASKET, THERMOSTAT COVER	1	2
16		47587A 2	BLOCK ASSEMBLY, WATER DIST	1	
17	22	32803	PLUG, PIPE - WATER DISTRIBL	1	
18	22	32802	PLUG, PIPE - WATER DISTRIBL	1	
19	27	33680	GASKET, WATER DISTRIBUTION	1	8
20	10	21077	SCREW, WATER DIISTRIBUTIOI	2	
21	22	53509	ELBOW, WATER DISTRIBUTION	1	
22	32	47640	HOSE, WATER DISTRIBUTION B	1	
23	54	32781	CLAMP, HOSE TO WATER DISTF	2	