



| Parts List |       |          |                               |     |                              |          |
|------------|-------|----------|-------------------------------|-----|------------------------------|----------|
| Ref        | Class | Part     | Description                   | Qty | Comment                      | Footnote |
| 1          | 32    | 52951A 1 | TUBING, HYDRAULIC PUMP TO     | 1   | WITHOUT GIMBAL TRIM SENDE    |          |
| 2          | 32    | 52951A 1 | TUBING, TRIM SENDER TO RESI   | 1   | WITHOUT GIMBAL TRIM SENDE    |          |
| 2A         | 32    | 52951A 1 | TUBING, HYDRAULIC PUMP TO     | 1   | WITH GIMBAL TRIM SENDER      |          |
| 2B         | 22    | 49718    | FITTING, NUT - HYDRAULIC TL   | 4   |                              |          |
| 3          | 32    | 55816    | HOSE, HYDRAULIC - CONNECTO    | 1   |                              |          |
| 4          | 54    | 45806    | CLAMP, HYDRAULIC HOSE TO TI   | 1   |                              |          |
| 5          | 10    | 35519    | SCREW, HYDRAULIC HOSE CLAI    | 1   |                              |          |
| 6          | 32    | 55815    | HOSE, HYDRAULIC - CONNNECT    | 1   | SERIAL 00000000-03780849     |          |
| 7          | 32    | 47373    | HOSE, HYDRAULIC - CONNNECT    | 4   | SERIAL 00000000-03780849     |          |
| 6          | 32    | 59842    | HOSE, HYDRAULIC - CONNNECT    | 1   | SERIAL 03780850-09999999     |          |
| 7          | 32    | 68676    | HOSE, HYDRAULIC - CONNNECT    | 4   | SERIAL 03780850-09999999     |          |
| 8          |       | 45706A 8 | TRIM CYLINDER ASSEMBLY, COI   | 2   | SEE PAGE 16 FOR REPAIR KIT E |          |
| 8          |       | 45522A 3 | PIVOT END REPAIR KIT, TRIM    | 2   | SEE PAGE 16 FOR REPAIR KIT E |          |
| 8          |       | 45706A 4 | OUTER TUBE REPAIR KIT, TRI    | 2   | SEE PAGE 16 FOR REPAIR KIT E |          |
| 8          | 25    | 60342A 2 | "O" RING REPAIR KIT, TRIM CY  | 2   | SEE PAGE 16 FOR REPAIR KIT E |          |
| 9          | 17    | 45735    | PIN, FRONT ANCHOR - TRIM CYL  | 1   |                              |          |
| 10         | 12    | 45737    | WASHER, FRONT ANCHOR PIN      | 2   |                              |          |
| 11         | 23    | 61290    | BUSHING, RUBBER - FRONT ANCH  | 4   |                              |          |
| 12         | 24    | 46312    | SPRING, FRONT ANCHOR PIN      | 2   |                              |          |
| 13         | 12    | 46765    | WASHER, FRONT ANCHOR PIN      | 2   |                              |          |
| 14         | 11    | 34932    | NUT, FRONT ANCHOR PIN         | 2   |                              |          |
| 15         | 17    | 45738    | PIN, REAR ANCHOR - TRIM CYLII | 1   |                              |          |
| 16         | 12    | 45737    | WASHER, REAR ANCHOR PIN       | 2   |                              |          |
| 17         | 23    | 61290    | BUSHING, RUBBER - REAR ANCH   | 4   |                              |          |
| 18         | 24    | 46312    | SPRING, REAR ANCHOR PIN       | 2   |                              |          |
| 19         | 12    | 46765    | WASHER, REAR ANCHOR PIN       | 2   |                              |          |
| 20         | 11    | 34932    | NUT, REAR ANCHOR PIN          | 2   |                              |          |