



Parts List					Qty	Comment	Footnote
Ref	Class	Part	Description				
1	424	3864	CAMSHAFT	1			
2	28	34466	KEY, CAMSHAFT GEAR LOCATI	1			
3	23	34469	BEARING, CAMSHAFT THRUST	1			
4	43	58283	GEAR, TIMING - CAMSHAFT	1			
5	10	34277	SCREW, TIMING GEAR TO CAMS	2			
6		46744	LIFTER, HYDRAULIC - TRAPPET	8			
7		65142A 1	WATER PUMP ASSEMBLY	1			
8	27	33956	GASEKT, WATER PUMP	1		1	
9	10	34471	SCREW, WATER PUMP TO CYLII	2			
10	10	34505	SCREW, WATER PUMP TO CYLII	2			
11		52349	PULLEY, WATER PUMP	1			
12	10	47277	SCREW, PULLEY TO WATER PU	4			
13	13	39107	LOCKWASHER, PULLEY SCREW	4			
14	32	46471	NOZZLE, OIL - TIMING GEAR	1			
15	57	64032	BELT, ALTERNATOR AND WATE	1			
16	613	3817	CONNECTING ROD ASSEMBLY	4			
17	10	52269	BOLT, CONNECTING ROD BEA	8			
18	11	37493	NUT, CONNECTING ROD CAP E	8			
19	23	85701	BEARING (PAIR), CONNECTING F	4			
19	23	85702	BEARING (PAIR), CONNECTING F	AR			
19	23	85703	BEARING (PAIR), CONNECTING F	AR			
19	23	85704	BEARING (PAIR), CONNECTING F	AR			
19	23	85705	BEARING (PAIR), CONNECTING F	AR			
20	423	3816	CRANKSHAFT	1			
21	28	34466	KEY, PULLEY AND GEAR LOCATI	2			
22	43	46743	GEAR, TIMING - CRANKSHAFT	1			
23		55045	BALANCER, HARMONIC	1			
24	220	8775	FLYWHEEL, CRANKSHAFT	1			
25	16	32808	STUD, FLYWHEEL TO ENGINE C	6			
26		32492A 5	ENGINE COUPLING ASSEMBLY	1			
27	12	35935	WASHER, FLYWHEEL STUD	6			
28	11	34933	NUT, FLYWHEEL STUD	6			