



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	424	3864	CAMSHAFT	1		
2	28	34466	KEY, CAMSHAFT GEAR LOCATI	1		
3	23	34469	BEARING, CAMSHAFT THRUST	1		
4	43	58283	GEAR, TIMING - CAMSHAFT	1		
5	10	34277	SCREW, TIMING GEAR TO CAMS	2		
6		46744	LIFTER, HYDRAULIC - TRAPPET	8		
7		65142A 1	WATER PUMP ASSEMBLY	1		
8	27	33956	GASEKT, WATER PUMP	1		1
9	10	34471	SCREW, WATER PUMP TO CYLII	2		
10	10	34505	SCREW, WATER PUMP TO CYLII	2		
11		52349	PULLEY, WATER PUMP	1		
12	10	47277	SCREW, PULLEY TO WATER PU	4		
13	13	39107	LOCKWASHER, PULLEY SCREW	4		
14	32	46471	NOZZLE, OIL - TIMING GEAR	1		
15	57	64032	BELT, ALTERNATOR AND WATE	1		
16	613	3817	CONNECTING ROD ASSEMBLY	4		
17	10	52269	BOLT, CONNECTING ROD BEAI	8		
18	11	37493	NUT, CONNECTING ROD CAP E	8		
19	23	85701	BEARING (PAIR), CONNECTING F	4		
19	23	85702	BEARING (PAIR), CONNECTING F	AR		
19	23	85703	BEARING (PAIR), CONNECTING F	AR		
19	23	85704	BEARING (PAIR), CONNECTING F	AR		
19	23	85705	BEARING (PAIR), CONNECTING F	AR		
20	423	3816	CRANKSHAFT	1		
21	28	34466	KEY, PULLEY AND GEAR LOCATI	2		
22	43	46743	GEAR, TIMING - CRANKSHAFT	1		
23		55045	BALANCER, HARMONIC	1		
24	220	8775	FLYWHEEL, CRANKSHAFT	1		
25	16	32808	STUD, FLYWHEEL TO ENGINE C	6		
26		32492A 5	ENGINE COUPLING ASSEMBLY	1		
27	12	35935	WASHER, FLYWHEEL STUD	6		
28	11	34933	NUT, FLYWHEEL STUD	6		