



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		87581	DISTRIBUTOR ASSEMBLY, COM	1		
2		62426	SCREEN, VENT - DISTRIBUTOR	2		
3	43	33664	GEAR, DRIVE - MAIN SHAFT	1		
4		87597	MAIN SHAFT AND WEIGHT PL	1		
5	17	33649	PIN, DRIVE GEAR TO MAIN SH	1		
6	12	58220	WASHER, CAM AND SHAFT	1		
7	26	72653	SEAL, HOUSING	1		
8		33653	FELT, BREAKER CAM LUBRICA	1		
		72654	RETAINER, BREAKER CAM LUF	1		
10		33665	PLATE, MOUNTING - BREAKER	1		
11	10	33648	SCREW, MOUNTING PLATE TC	2		
11A	12	62425	WASHER, BREAKER PLATE SL	2		
12		33662	CONDENSER	1		
--		48024	BRACKET, CONDENSER MOUN	1		
--	10	48021	SCREW, CONDENSER BRACKE	1		
13		34235	BREAKER ASSEMBLY, DISTRIE	1		
14	10	33650	SCREW, BREAKER ASSEMBLY	1		
16	25	33666	GROMMET, MOUNTING PLKAT	1		
17		33658	LEAD, PRIMARY	1		
18		58217	ROTOR, DISTRIBUTOR	1		
19	12	36275	WASHER, ROTOR	1		
20		33667	CAP, DISTRUBTOR	1		
22	10	33660	SCREW, DISTRIBUTOR CAP TC	1		
23	10	33663	SCREW, DISTRIBUTOR CAP TC	1		
24	27	34486	GASKET, DISTRIBUTOR	1		1
25	84	92151A36	LEAD ASSEMBLY, HIGH TENSIO	4		
27	85	63709A 1	PROTECTOR, HIGH TENSION L	4		
--		60096	SLEEVE, TERMINAL END COVE	4		
28	33	59571	SPARK PLUB (AC#R43T)	4		
29		32782	RETAINER, HIGH TENSION LEAC	1		
31	84	67203	WIRE, DISTRIBUTOR TO COIL (1	1		
32		32193	COIL, IGNITION	1		
33		65970	BRACKET, IGNITION COIL MOUN	1		
34	10	66652	SCREW, MOUNTING BRACKET T	1		
35	12	30164	WASHER, IGNITION COIL TERMI	2		
36	13	26996	LOCKWASHER, IGNITION COIL T	2		
37	11	68219	NUT, IGNITION COIL TERMINAL	2		
38	10	27165	SCREW, IGNITION COIL TO CYLII	1		
39	12	20553	WASHER, IGNITION COIL SCREW	1		
40	10	35169	SCREW, DISTRIBUTOR TO CYLII	1		
41		72624	CLAMP UNIT, DISTRIBUTOR	1		