



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		38057	ELBOW, WATER OUTLET - CYLIN	1		
2	32	38066	HOSE, WATER OUTLET ELBOW	1		
3	54	32780	CLAMP, WATER OUTLET ELBOW	2		
4	27	33680	GASKET, WATER OUTLET ELBO	1		
5	22	32804	PLUG, PIPE - WATER OUTLET EI	1		
6	10	21077	SCREW, WATER OUTLET ELBO	2		
7	22	33060	NIPPLE, BLEED HOSE TO WATEI	1		
8		38058A 1	COVER ASSEMBLY, WATER INLE	1		
9	27	38061	GASKET, M WATER INLET COV	1		
10	22	38060	CAP, WATER INLET COVER	1		
11	27	35144	GASKET, WATER INLET COVER	1		
12	10	35388	SCREW, WATER INLET COVER	7		
13		35155	BODY, EXHAUST MANIFOLD	1		
14	10	25299	SCREW, WATER PUMP FLANGE	1		
15		35149	ELBOW, WATER OUTLET - EXHA	1		
16	27	35150	GASKET, EXHAUST MANIFOLD E	1		
17	10	35388	SCREW, WATER OUTLET ELBO	5		
18	32	33484	HOSE, WATER OUTLET ELBOW	1		
19	54	32781	CLAMP, HOSE TO WATER OUTL	2		
20		32877	COVER, WATER PUMP	1		
21	54	38426	CLAMP, WATER PUMP COVER T	1		
22	27	46401	GASKET, EXHAUST MANIFOLD B	1		
23		38980	COVER, INTAKE MANIFOLD (NOT	1		
24	27	39256	GASKET, INTAKE MANIFOLD COV	1		
25	10	38326	SCREW, INTAKE MANIFOLD COV	9		
26	10	38327	SCREW, INTAKE MANIFOLD COV	9		
27	22	36382	PLUG, PIPE - INTAKE MANIFOLD	1		
28	16	34612	STUD, EXHAUST MANIFOLD BO	6		
29	10	21077	SCREW, EXHAUST MANIFOLD BI	2		
30	12	20553	WASHER, EXHAUST MANIFOLD	8		
31	13	37459	LOCKWASHER, EXHAUST MANIF	8		
32	11	24883	NUT, EXHAUST MANIFOLD BO	6		
33	54	33461	CLAMP, DRAIN HOSE TO EXHAU	1		
34	10	29240	SCREW, DRAIN HOSE CLAMP TC	1		
35	22	32715	ELBOW, WATER INLET HOSE - E	1		
36	32	33117	HOSE, WATER INLET-EXHAUST	1	DRIVE UNIT (35")	
37	54	32779	CLAMP, WATER INLET HOSE FA	2		
38	27	35152	GASKET, BAFFLE PLATE TO EXH	1		
39		35151	PALTE, BAFFLE - EXHAUST MAN	1		
40	27	35154	GASKET, EXHAUST MANIFOLD C	1		
41		25152	COVER, EXHAUST MANIFOLD	1		