



| Parts List | | | | | | |
|------------|-------|----------|----------------------------|-----|--------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | 50 | 45120 | STARTER MOTOR ASSEMBLY | 1 | SEE NOTE | |
| 2 | 10 | 34545 | BOLT, STARTER MOTOR MOUN | 1 | | |
| 3 | 10 | 34544 | BOLT, STARTER MOTOR MOUN | 1 | | |
| 4 | | 34546 | BRACE, STARTER MOTOR | 1 | SERIAL 00000000-02492035 | |
| 5 | 10 | 48543 | SCREW, BRACE TO MOTOR ANC | 2 | SERIAL 00000000-02492035 | |
| 6 | | 52250 | BRACE, STARTER MOTOR | 1 | SERIAL 02492036-09999999 | |
| 7 | 16 | 52387 | STUD, BRACE TO MOTOR AND C | 2 | SERIAL 02492036-09999999 | |
| 8 | 12 | 20103 | WASHER, BRACE STUD | 2 | SERIAL 02492036-09999999 | |
| 9 | 11 | 35814 | MUT, BRACE STUD | 2 | SERIAL 02492036-09999999 | |
| 10 | 11 | 28517 | NUT, SOLENOID SWITCH TERMI | 1 | | |
| 11 | 11 | 26419 | NUT, SOLENOID SWITCH TERMI | 1 | | |
| 12 | 13 | 26995 | LOCKWASHER, STARTER MOTO | 1 | | |
| 13 | 11 | 26419 | NUT, STARTER MOTOR TERMIN | 1 | | |
| 14 | | 37615A 1 | ALTERNATOR ASSEMBLY | 1 | SERIAL 00000000-02768031 | |
| 14 | | 56045 | ALTERNATOR ASSEMBLY | 1 | SERIAL 02768032-09999999 | |
| 14 | 10 | 20055 | SCREW, WIRING HARNESS LEA | 1 | SERIAL 02768032-09999999 | |
| 14 | 13 | 26996 | LOCKWASHER, WIRING HARNE | 1 | SERIAL 02768032-09999999 | |
| 14 | 12 | 30164 | WASHER, WIRING HARNESS LE | 1 | SERIAL 02768032-09999999 | |
| 15 | | 32754 | BRACE, ALTERNATOR TO CYLIN | 1 | | |
| 16 | 10 | 27165 | SCREW, ALTERNATOR BRACE T | 1 | | |
| 17 | 13 | 37459 | LOCKWASHER, ALTERNATOR BI | 1 | | |
| 18 | 12 | 20553 | WASHER, ALTERNATOR BRACE | 1 | | |
| 19 | 10 | 29198 | SCREW, ALTERNATOR BRACE T | 1 | | |
| 20 | 12 | 26168 | WASHER, ALTERNATOR BRACE | 1 | | |
| 21 | 10 | 32775 | SCREW, ALTERNATOR TO BRAC | 1 | SERIAL 00000000-02768031 | |
| 21 | 10 | 56057 | SCREW, ALTERNATOR TO BRAC | 1 | SERIAL 02768032-09999999 | |
| 22 | 23 | 32727 | SPACER, ALTERNATOR SCREW | 1 | | |
| 23 | 11 | 25269 | NUT, ALTERNATOR SCREW | 1 | | |
| 24 | | 32753 | BRACKET, ALTERNATOR MOUN | 1 | SERIAL 00000000-02492035 | |
| 24A | | 52817 | BRACKET, ALTERNATOR MOUN | 1 | SERIAL 02492036-09999999 | |
| 25 | 10 | 33524 | SCREW, ALTERNATOR MOUNTII | 1 | | |
| 26 | 13 | 26993 | LOCKWASHER, ALTERNATOR M | 1 | | |
| 27 | 12 | 26825 | WASHER, ALTERNATOR MOUNT | 1 | | |
| 28 | | 46475 | BRACKET, ALTERNATOR MOUN | 1 | SERIAL 00000000-02492035 | |
| 28A | | 52818 | BRACKET, ALTERNATOR MOUN | 1 | SERIAL 02492036-09999999 | |
| 29 | 10 | 27165 | SCREW, ALTERNATOR MOUNTII | 1 | SERIAL 00000000-02492035 | |
| 30 | 13 | 37459 | LOCKWASHER, ALTERNATOR M | 1 | SERIAL 00000000-02492035 | |
| 31 | 12 | 20553 | WASHER, ALTERNATOR MOUNT | 1 | SERIAL 00000000-02492035 | |
| 32 | 10 | 26632 | SCREW, ALTERNATOR MOUNTII | 1 | SERIAL 00000000-02492035 | |
| 33 | 13 | 37459 | LOCKWASHER, ALTERNATOR | 1 | SERIAL 00000000-02492035 | |
| 34 | 12 | 20553 | WASHER, ALTERNATOR MOUNT | 1 | SERIAL 00000000-02492035 | |