



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		89953A	INTAKE MANIFOLD ASSEMBLY	1	
2	22	36382	PLUB, INTAKE MANIFOLD - TOP	1	
3	10	28642	SCREW, DRIVE - WATER TUPE	4	
4	27	70905	GASKET, INTAKE MANIFOLD	1	2
5	10	68101	SCREW, INTAKE MANIFOLD TO (7	
6	12	25909	WASHER, INTAKE MANIFOLD SC	7	
7	22	73817	FITTING, INTAKE MANIFOLD	1	
8	32	89713	HOSE, INTAKE MANIFOLD TO RE	1	
9	54	54428	CLAMP, HOSE ATTACHING	2	
10		78801T	LEVER, INTERMEDIATE THROTT	1	
11	12	35950	WASHER, INTERMEDIATE THRC	1	
12	12	30164	WASHER, INTERMEDIATE THRC	1	
13	11	20110	NUT, INTERMEDIATE THROTTLE	1	
14	10	38507	SCREW, LEVER TO INTAKE MAN	1	
15	12	20553	WASHER, LEVER SCREW	1	
16	12	57792	WASHER, LEVER SCREW	1	
17		27947	SWIVEL, LINKAGE	1	
18		64804	LINK ROD, LINKAGE	1	
19		63145A	LINK ROD ASSEMBLY, LINKAGE	1	
20		38983	SWIVEL, LINKAGE - CARBURETC	1	
21	12	35950	WASHER, SWIVEL LINKAGE - CA	1	
22	12	30164	WASHER, SWIVEL LINKAGE - CA	1	
23	11	20110	NUT, SWIVEL LINKAGE - CARBUI	1	
24	16	38525	STUD, THROTTLE CABLE ANCH	1	
25	12	24664	WASHER, THROTTLE CABLE AN	2	
26	11	20586	NUT, THROTTLE CABLE ANCHOI	1	
27	10	64969	SCREW, THROTTLE STOP	1	
28	11	33122	NUT, THROTTLE STOP SCREW	1	
29	32	76326	HOSE, INTAKE MANIFOLD TO W	1	
30	54	32780	CLAMP, HOSE TO WATER PUMP	1	
31	54	32781	CLAMP, HOSE TO INTAKE MANIF	1	
32	32	89655	HOSE, INTAKE MANIFOLD	1	
33	54	32781	CLAMP, HOSE TO INTAKE MANIF	2	