



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		99237A10	SHIFT BRACKET ASSEMBLY	1		
2	16	98798	STUD, SHIFT CABLE	1		
3	16	96108	STUD, SHIFT BRACKET	2		
4		13051A 4	LEVER ASSEMBLY, ACTUATING	1		
5	24	45599	SPRING, ACTUATING LEVER	1		
6	10	88743	SCREW, SPRING TO LEVER	1		
7	12	56720	WASHER, SPRING SCREW	1		
8	23	98828	SPACER, RUBBER PAD	1		
9	18	32857	COTTER PIN, SHIFT BRACKET S	1		
10	12	56720	WASHER, SHIFT BRACKET STU	5		
11	23	37981	SPACER, SHIFT BRACKET STU	2		
12	23	45600	SLEEVE, ACTUATING LEVER	1		
13	11	35814	NUT, SHIFT BRACKET STU	2		
14		39670A28	SWITCH ASSEMBLY, CUT-OUT	1		
15	10	30902	SCREW, SWITCH TO SHIFT BRA	2		
16	86	66986	TERMINAL BLOCK	1		
17	10	96113	SCREW, TERMINAL BLOCK (7/8"	1		
18	10	73287	SCREW, TERMINAL BLOCK (3/8"	1		
19	13	26996	LOCKWASHER, TERMINAL BLOC	2		
20		13898A 3	SHIFT LEVER ASSEMBLY	1		
21	16	98851	STUD, SHIFT CABLE	1		
22	23	45600	SLEEVE, SHIFT LEVER	1		
23	16	96112	STUD, SHIFT CABLE	1		
24	12	35462	WASHER, SHIFT CABLE STU	4		
25	11	63341	TEE NUT, SHIFT CABLE STU	1		
26	23	98820	SPACER, SHIFT CABLE STU	1		
27	24	98880	SPRING, SHIFT CALBE STU	1		
28	11	35888	NUT, SHIFT CABLE STU	3		