



SERIAL #3780850 and up

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		49701A 2	PLATE ASSEMBLY,TRANSOM(W)	1		
1		65550A 2	PLATE ASSEMBLY,TRANSOM(W)	1		
2		66058	BRACKET,SHIFT MOUNTING	1		
3	10	25038	SCREW,SHIFT MOUNTING BRAC	3		
4	13	21804	LOCKWASHER,SHIFT MOUNTING	3		
5		66057A 3	SHIFT BRACKET ASSEMBLY	1		
6	16	47360	STUD,SHIFT CABLE TO SHIFT I	1		
7	16	73563	STUD,SWITCH ACTUATING AR	1		
8	10	35386	SCREW,SHIFT BRACKET TO SHI	3		
9	13	21804	LOCKWASHER,SHIFT BRACKET	3		
10	12	39143	WASHER,SHIFT CABLE STUD	3		
11	11	20361	NUT,SHIFT CABLE STUD	1		
12		45517A 2	ARM ASSEMBLY,SWITCH ACTUA	1		
13	23	45600	SLEEVE,SWITCH ACTUATING S	1		
14	24	45599	SPRING,TENSION-SWITCH AC	1		
15	10	33231	SCREW,TENSION SPRING TO	1		
16	12	26825	WASHER,TENSION SPRING SC	1		
17	18	32857	COTTER PIN,SHIFT ACTUATING	1		
18	23	37981	SPACER,SWITCH ACTUATING AF	1		
19	12	26825	WASHER,SWITCH ACTAUITING A	1		
20	11	35814	NUT,SWITCH ACTUATING ARM S	1		
21		66397A 1	LEVER ASSEMBLY,SHIFT CONTE	1		
22	16	63335	STUD,SHIFT ACTUATING CABL	1		
23	12	39143	WASHER,SHIFT ACTUATING C	2		
24	11	63341	NUT,SHIFT ACTAUITING CABL	1		
25	11	20361	NUT,SHIFT CABLE STUD	1		
26	16	47360	STUD,SHIFT CABLE TO LEVER	1		
27	23	31866	SPACER,SHIFT CABLE STUD	1		
28	12	39143	WASHER,SHIFT CABLE STUD	1		
29	11	20361	NUT,SHIFT ACTUATING LEVER	1		
30		39670A 5	SWITCH ASSEMBLY,CUT-OUT-SI	1		
31	10	30902	SCREW,SWITCH ASSEMBLY TO	2		
32	86	66986	TERMINAL BLOCK,CUT-OUT SWI	1		
33	10	24637	SCREW,GROUND LEADS-TERMI	1		
34	10	45218	SCREW,CUT-OUT SWITCH LEAD	1		
35	13	26996	LOCKWASHER,TERMINAL BLOC	2		