



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	52951A 1	TUBING, HYDRAULIC PUMP TO	1	WITHOUT GIMBAL TRIM SENDE	
2	32	52951A 1	TUBING, TRIM SENDER TO RESI	1	WITHOUT GIMBAL TRIM SENDE	
2A	32	52951A 1	TUBING, HYDRAULIC PUMP TO F	1	WITH GIMBAL TRIM SENDER	
2B	22	49718	FITTING, NUT - HYDRAULIC TL	4		
3	32	55816	HOSE, HYDRAULIC - CONNECTO	1		
4	54	45806	CLAMP, HYDRAULIC HOSE TO TI	1		
5	10	35519	SCREW, HYDRAULIC HOSE CLAI	1		
6	32	55815	HOSE, HYDRAULIC - CONNNECT	1	SERIAL 00000000-03780849	
7	32	47373	HOSE, HYDRAULIC - CONNNECT	4	SERIAL 00000000-03780849	
6	32	59842	HOSE, HYDRAULIC - CONNNECT	1	SERIAL 03780850-09999999	
7	32	68676	HOSE, HYDRAULIC - CONNNECT	4	SERIAL 03780850-09999999	
8		45706A 8	TRIM CYLINDER ASSEMBLY, COI	2	SEE PAGE 16 FOR REPAIR KIT E	
8		45522A 3	PIVOT END REPAIR KIT, TRIM	2	SEE PAGE 16 FOR REPAIR KIT E	
8		45706A 4	OUTER TUBE REPAIR KIT, TRI	2	SEE PAGE 16 FOR REPAIR KIT E	
8	25	60342A 2	"O" RING REPAIR KIT, TRIM CY	2	SEE PAGE 16 FOR REPAIR KIT E	
9	17	45735	PIN, FRONT ANCHOR - TRIM CYL	1		
10	12	45737	WASHER, FRONT ANCHOR PIN	2		
11	23	61290	BUSHING, RUBBER - FRONT ANCH	4		
12	24	46312	SPRING, FRONT ANCHOR PIN	2		
13	12	46765	WASHER, FRONT ANCHOR PIN	2		
14	11	34932	NUT, FRONT ANCHOR PIN	2		
15	17	45738	PIN, REAR ANCHOR - TRIM CYLII	1		
16	12	45737	WASHER, REAR ANCHOR PIN	2		
17	23	61290	BUSHING, RUBBER - REAR ANCH	4		
18	24	46312	SPRING, REAR ANCHOR PIN	2		
19	12	46765	WASHER, REAR ANCHOR PIN	2		
20	11	34932	NUT, REAR ANCHOR PIN	2		