



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	222	6355	FLYWHEEL, CRANKSHAFT	1		
2	16	32808	STUD, FLYWHEEL TO ENGINE C	6		
3		32492A 5	ENGINE COUPLING ASSEMBLY	1		
4	12	35935	WASHER, FLYWHEEL STUD	6		
5	11	34933	NUT, FLYWHEEL STUD	6		
6	613	2277	CONNECTING ROD ASSEMBLY	6		
7	10	75539	BOLT, CONNECTING ROD BEA	12		
8	11	58099	NUT, CONNECTING ROD CAP E	12		
9	23	85677	BEARING (PAIR), CONNECTING F	6		
9	23	85707	BEARING (PAIR), CONNECTING F	AR		
9	23	85679	BEARING (PAIR), CONNECTING F	AR		
9	23	85680	BEARING (PAIR), CONNECTING F	AR		
9	23	85681	BEARING (PAIR), CONNECTING F	AR		
10	430	3161	CAMSHAFT	1		
11		46744	LIFTER, VALVE - TAPPET	12		
12	22	87238	DRAIN COCK	1		
14		65142	WATER PUMP ASSEMBLY (SPEC	1		
15	27	33956	GASKET, WATER PUMP	1		
16	10	34471	SCREW, WATER PUMP TO CYLI	2		
17	10	35339	SCREW, WATER PUMP TO CYLI	1		
17	10	34505	SCREW, WATER PUMP TO CYLI	2		
18		52349	PULLEY, WATER PUMP	1		
19	10	47277	SCREW, PULLEY AND HUB TO W	4		
20	13	39107	LOCKWASHER, PULLEY AND HU	4		
22	23	34469	BEARING, CAMSHAFT THRUST	1		
23	43	46745	GEAR, TIMING - CAMSHAFT (ALU	1		
24	28	34466	KEY, PULLEY AND GEAR LOCATI	3		
25	10	21417A 1	SCREW, TIMING GEAR TO CAMS	2		
26	57	64032	BELT, ALTERNATOR, WATER PL	1		
27	425	6516	CRANKSHAFT	1		
28	43	46743	GEAR, CRANKSHAFT	1		
29		75574	BALANCER, HARMONIC - CRANK	1		