



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
	1351	4282A 1	CARBURETOR ASSEMBLY, COM	1	SERIAL 00000000-03354701	
	1351	4871A 1	CARBURETOR ASSEMBLY, COM	1	SERIAL 03354702-03774864	
	1351	5204A 1	CARBURETOR ASSEMBLY, COM	1	SERIAL 03774865-09999999	
1		N. S. S.	AIR HORN (ROCHESTER 7041)	1		
2		N. S. S.	POWER PISTON ASSEMBLY (R	1		
3			GASKET, AIR HORN	1		3,4
4	10	33043	SCREW, AIR HORN TO FLOAT	7		
5	10	33048	SCREW, AIR HORN TO FLOAT	1		
6	13	26996	LOCKWASHER, AIR HORN SCF	8		
7	11	33631	NUT, FUEL INLET-AIR HORN (S	1		
7	1397	4337	NUT, FUEL INLET-AIR HORN (N	1		
7	1397	3330	NUT, FUEL INLET-AIR HORN	1	SERIAL 03774865-09999999	
8	35	53336	FILTER, FUEL INLET-AIR HORN	1		
9	24	48143	SPRING, FUEL INLET-AIR HORI	1		
10			GASKET, FUEL INLET NUT (LAF	1		3,4
11			GASKET, FUEL INLET FILTER (	1		3,4
12	1397	2060	FLOAT ASSEMBLY	1		
13		N. S. S.	PIN, HINGE-FLOAT TO AIR HOF	1		
14			CLIP, HINGE PIN	1		4
15			INLET NEEDLE AND SET ASSE	1		4
16			GASKET, INLET NEEDLE ANS	1		3,4
17	1397	4258	FLOAT BOWL ASSEMBLY	1		
18		N. S. S.	VENTURI CLUSTER ASSEMBLY	1	SERIAL 00000000-03354701	
18		N. S. S.	VENTURI CLUSTER ASSEMBLY	1	SERIAL 03354702-09999999	
19			GASKET, VENTURI CLUSTER	1		3,4
20		N. S. S.	SCREW, VENTURI CLUSTER T	1		
21			GASKET, VENTURI CLUSTER E	1		3,4
22		N. S. S.	SCREW, VENTURI CLUSTER TC	2		
23	13	26995	LOCKWASHER, VENTURI CLUS	2		
24			GUIDE, PUMP DISCHARGE-FLC	1		
25			SPRING, PUMP DISCHARGE-FL	1		
26			BALL, PUMP DISCHARGE-FLOA	1		
27			POWER VALVE ASSEMBLY, FL	1		
28			GASKET, POWER VALVE	1		3,4
29	1397	3827	JET, FLOAT BOWL (STANDARC	1		
30			STRINER, PUMP INLET	2		
31		N. S. S.	LEVER, PUMP-AIR HORN (ROC	1		
32	10	33047	SCREW, AIR HORN PUMP LEVI	1		
33		N. S. S.	PUMP SHAFT AND LEVER ASS	1		
34		N. S. S.	ROD, PUMP (ROCHESTER #70:	1		
35			CLIP, RETAINER PUMP ROD	1		4