



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		79550A 1	BRACKET, MOUNTING - ENGINE	2		
2	10	37612	SCREW, MOUNTING BRACKET T	2		
3	13	35048	LOCKWASHER, MOUNTING BRA	2		
2	10	68101	SCREW, MOUNTING BRACKET T	1		
3	12	46132	WASHER, MOUNTING BRACKET	1		
2	10	37612	SCREW, MOUNTING BRACKET T	2		
3	13	35048	LOCKWASHER, MOUNTING BRA	2		
4	16	64066	STUD, MOUNTING BRACKET TO	1		
5	54	92850	CLIP, WIRING HARNESS STARB	1		
6	13	35048	LOCKWASHER, MOUNTING BRA	1		
7	11	32219	NUT, MOUNTING BRACKET STU	1		
8		98323A 6	BASE, ENGINE MOUNT	2		
9	11	20739	NUT, JAM - ENGINE MOUNT BAS	6		
10	13	68102	LOCKWASHER, MOUNTING BRA	2		
11	16	41012	STUD, ENGINE MOUNTING	2		
12	12	41150	WASHER, SUPPORT	2		