



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-		32701	ALTERNATOR ASSEMBLY	1		
1		33331	ROTOR	1		
2		33325	STATOR ASSEMBLY	1		
3	54	33329	CLIP, TERMINAL - STATOR	3		
4		33263	COLLAR, DRIVE END FRAME - I	1		
5	25	33312	SLINGER, GREASE - DRIVE EN	1		
6	30	20802	BEARING, BALL - DRIVE END F	1		
7	27	33273	GASKET, BALL BEARING RETA	1		
8		33319	PLATE, BALL BEARING RETAIN	1		
9	10	33323	SCREW, BALL BEARING RETAI	3		
10		33343	FRAME, DRIVE END	1		
11		33344	COLLAR, DRIVE END FRAME - I	1		
12		33336	FAN, DRIVE END FRAME	1		
13		36105	PULLEY, DRIVE END FRAME	1		
14	13	33309	WASHER, WAVE - ROOT NUT	1		
15	11	33272	NUT, ROTOR TO DRIVE END F	1		
16		33349	FRAME ASSEMBLY, SLIP RING	1		
17		33341	DIODE PACKAGE, SLIP RING	3		
18	26	33348	SEAL, SLIP RING END FRA	1		
19	31	33355	BEARING, ROLLER - SLIP RIN	1		
20	26	33339	SEAL, SLIP RING END FRAME	1		
21		33327	CONDENSER	1		
22		33345	RETAINER, SLIP RING END F	1		
23		33350	HEAT SINK ASSEMBLY, SLIP R	1		
24		33342	TERMINAL PACKAGE, DIODE	3		
25		33340	DIODE PACKAGE, HEAT SINK	3		
26		33332	STRAP, DIODE JUNCTION TER	1		
27	13	34383	LOCKWASHER, DIODE JUNCTI	3		
28	11	26419	NUT, DIODE JUNCTION TERMI	3		
29	10	24609	SCREW, CONDENSER TERMIN	1		
30	13	34383	LOCKWASHER, CONDENSER T	1		
31	12	20192	WASHER, CONDENSER TERMI	1		
32		33326	INSULATOR, CONDENSER TEF	1		
33	12	33328	WASHER, INSULATING - CON	1		
34		33353	RELAY TERMINAL PACKAGE, F	1		
35		33352	BATTERY TERMINAL PACKAGE	1		
36		33346	TERMINAL GROUND - SLIP RIN	1		
37	12	20192	WASHER, GROUND TERMINAL	1		
38	13	26995	LOCKWASHER, GROUND TER	2		
39	11	26419	NUT, GROUND TERMINAL	1		
40		24754	BRUSH HOLDER PACKAGE	1	SEE NOTE	