



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	50	99417A 2	STARTER MOTOR ASSEMBLY	1	
1		71696	HOUSING, DRIVE END	1	
2	23	33369	BUSHING, DRIVE END HOUS	1	
3		33292	COLLAR, THRUST	1	
4	53	33290	RING,RETAINING-PINION STOP	1	
5		33291	COLLAR, PINION STOP	1	
6		79205	DRIVE ASSEMBLY, CLUTCH	1	
7		N.S.S.	PLATE, BEARING(DELCO-REMY	1	1
8	23	71694	BUSHING, BEARING PLATE	1	
9	12	68614	WASHER, BEARING PLATE	1	
10	10	79209	SCREW, BEARING PLATE	2	
11		75665	ARMATURE BEARING	1	5
11		71693	ARMATURE	1	7
12		N.S.S.	SHOE,POLE (DELCO-REMY #19	4	7,1
12		N.S.S.	SHOE,POLE (DELCO-REMY #81	4	5,1
12		N.S.S.	SCREW, POLE SHOE TO FIELD	4	1
14	25	79208	GROMMET, FIELD COIL - FIELD	1	
15		79212	FIELD COIL ASSEMBLY	1	7
15		75664	FIELD COIL ASSEMBLY	1	5
16	12	33258	WASHER, LEATHER-COMMUTA	2	
17		79211	FRAME, COMMUTATOR END - I	1	
18		N.S.S.	BOLT,THRU (DELCO-REMY #19	1	1
18		N.S.S.	BOLT, THRU-W/EXTENSION (C	1	1
19		33284	HOLDER, INSULATED-FIELD FF	2	
20		33283	HOLDER, FIELD FRAME BRUSH	2	
21		33270	BRUSH, FIELD FRAME	4	
22		N.S.S.	SCREW,BRUSH LEAD(DELCO-F	2	1
23		33294	SUPPORT PACAKGE, GROUND	2	
24	24	33285	SPRING, FIELD FRAME BRUSH	4	
25		N.S.S.	PIN, DOWEL-FIELD FRAME (DE	1	1
26		33297	LEVER,SHIFT-EARLY STYLE	1	
27		N.S.S.	STUD, SHIFT LEVER (DELCO-R	1	1
28	12	68615	WASHER, SHIFT LEVER STUD	1	
29	11	26484	NUT, SHIFT LEVER STUD -EAR	1	
26		71698	LEVER, SHIFT NEW STYLE	1	
30		N.S.S.	PIN (DELCO-REMY #1945804) N	1	1
31	53	33354	RETAINING RING NEW STYLE	1	
32		33317	PLUNGER, SHIFT LEVER	1	
33	17	79207	PIN, PLUNGER TO SHIFT LEVE	1	
34	24	46889	SPRING,PLUNGER RETURN	1	
35		N.S.S.	SCREW, SOLENOID SWITCH (F	2	1