



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		70981A	EXHAUST BELLOWS	2		
2	54	33683	CLAMP (SMALL)	12		
3	54	31765	CLAMP (LARGE)	4		
4		94443A	EXHAUST ELBOW - CASTING #9	2	EARLY MODELS	
4A		94443A	EXHAUST ELBOW (STDB) - CAST	1	LATER MODELS	
4A		94444A	EXHAUST ELBOW (PORT) - CAST	1	LATER MODELS	
5	32	90949	EXHAUST TUBE	2		
6		99370A	WATER SHUTTER	2		
7		94981A	EXHAUST PIPE (USE WITH REF.	1		
7A		99877A	EXHAUST PIPE (USE WITH REF.	1		
8	10	58640	SCREW, EXHAUST PIPE TO STE	4		
9	13	41471	LOCKWASHER, EXHAUST PIPE	4		