



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		72646	INTAKE MANIFOLD (228-230)	1		
1		78779	INTAKE MANIFOLD (898-200)	1		
2	10	11976	BOLT, INTAKE MANIFOLD	9		
2		N.S.S.	BOLT, INTAKE MANIFOLD (GM #:	3		
3	12	49112	WASHER, INTAKE MANIFOLD BC	3		
4	54	47512	EYE, LIFTING	1		
5	10	34353	SCREW, LIFTING EYE	1		
6		N.S.S.	STUD, GUARD (GM #3959544)	4		
7		72647	GUARD, INTAKE MANIFOLD	1		
8	27	72637	GASKET, SET, INTAKE MANIFOLD	1		4
9		60658	WATER PUMP ASSEMBLY	1		
10	27	34897	GASKET, WATER PUMP MOUN	2		4
11	10	32132	SCREW, WATER PUMP TO CYLI	2		
11	10	47688	SCREW, WATER PUMP TO CYLI	1		
11	10	52200	SCREW, WATER PUMP TO CYLI	1		
12		90840A 1	PULLEY, WATER PUMP (3 GROO	1		
13	10	47277	SCREW, PULLEY TO WATER PU	4		
14	13	39107	LOCKWASHER, WATER PUMP P	4		
15		75420	BALANCER, HARMONIC - CRANK	1		
16		33863	PULLEY, HARMONIC BALANCER	1		
17		90841A 1	PULLEY, (1 GROOVE) (w/POWE	1		
18	10	72626	BOLT, PULLEY AND HARMONIC	1		
19	13	39131	LOCKWASHER, PULLEY AND HA	1		
20	12	35332	WASHER, PULLEY AND HARMON	1		
21	10	34352	BOLT, PULLEY (7/8") (w/O POW	3		
21	10	35786	BOLT, PULLEY (1") (w?POWER E	3		
22	13	35048	LOCKWASHER, PULLEY BOLT	3		
23	57	49213A 1	BELT, ALTERNATOR DRIVE (44"	1		
24		35365	SUPPORT, SPARK PLUG LEAD W	2		
25	10	35366	SCREW, LEAD WIRE SUPPORT (	2		
26		60660A 1	COVER, CRANKCASE FRONT	1		9
27	26	97335	OIL SEAL, COVER	1		4,9
28	27	34895	GASKET, COVER	1		4,9
26		14249A 1	COVER, CRANKCASE FRONT	1		8
27	26	97335	OIL SEAL, COVER	1		4,8
28	27	14250	GASKET, COVER	1		4,8
29	10	35366	SCREW, COVER	10		
31		53338	FILTER VALVE	1		
32	10	54786	SCREW, FILTER VALVE TO CYLI	2		
33		52731	OIL FILTER	1		
34		14229	RETAINER, OIL SEAL (REAR)	1		8