



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		52134	BRACKET, MOUNTING (FRONT-F	1		
2		52811	TIE BAR, FRONT MOUNT CONNE	1		
3	13	31848	LOCKWASHER, TIE BAR	2		
4	11	52829	NUT, TIE BAR FASTENING	4		
5	16	52605	STUD, MOUNTING BRACKET TO	2		
5	16	52606	STUD, MOUNTING BRACKET TO	1		
6	13	37459	LOCKWASHER, MOUNTING BRA	3		
7	11	49838	NUT, MOUNTING BRACKET STU	3		
8		52078	BRACKET, MOUNTING (FRONT-S	1		
9	16	52605	STUD, MOUNTING BRACKET TO	3		
10	13	37459	LOCKWASHER, MOUNTING BRA	3		
11	11	49838	NUT, MOUNTING BRACKET STU	3		
12	10	47654	SCREW, CLAMP-ADJUSTING TRI	4		8
13	13	32993	LOCKWASHER, CLAMP ADJUSTI	4		8
14	54	47528	CLAMP, ADJUSTING TRUNNION	8		8
15	11	29553	NUT, CLAMP ADJUSTING TRUNN	4		8
16		47986	BRACKET, MOUNTING-ENGINE	4		8
17		52139A 2	BRACKET ASSEMBLY, MOUNTIN	4	SERIAL 00000000-02494935	
17		52139A 4	BRACKET ASSEMBLY, MOUNTIN	2	SERIAL 24994936-09999999	
18		47656	MOUNT, MOUNTING BRACKET	8	SERIAL 00000000-02494935	
18		52753	MOUNT, MOUNTING BRACKET	4	SERIAL 24994936-09999999	
19	12	48611	WASHER, MOUNTING BACKET	8		8
20	10	48254	SCREW, MOUNTING BRACKET A	8		8
21	13	31848	LOCKWASHER, MOUNTING BRA	8		8
22	10	52156	SCREW ADJUSTING TRUNNION	4		8
23	14	48467	TAB WASHER, ADJUSTER TRUN	4		8
24		47518	TRUNNION, ADJUSTING-MOUNT	4		8
25	11	47525	NUT, JAM-ADJUSTING TRUNNIC	4		8
26	17	22116	PIN, ROLL-JAM NUT	4		8