



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		11974	INTAKE MANIFOLD (185)	1		
1		42752	INTAKE MANIFOLD (205)	1		
2	10	11976	BOLT, INTAKE MANIFOLD	8		
2	10	11975	BOLT, INTAKE MANIFOLD	4		
3	22	75983	PLUG, VACUUM HOLE	1		
4		42453	BRACKET, LIFTING (FRONT)	1		
4		42745	BRACKET, LIFTING (REAR)	1		
5	10	34354	SCREW, LIFTING BRACKET (1-1/2)	1		
6		N.S.S.	STUD, GUARD TO INTAKE MANIFOLD	4		
7		42753	GUARD, INTAKE MANIFOLD	1		
8	27	11977	GASKET SET, INTAKE MANIFOLD	1		4
9		60658	WATER PUMP ASSEMBLY	1		
10	27	34897	GASKET, WATER PUMP MOUNT	2		4
11	22	48336	PLUG, WATER PUMP	1		
12	10	32132	SCREW, WATER PUMP TO CYLINDER	1		
12	10	47688	SCREW, WATER PUMP TO CYLINDER	1		
12	10	52200	SCREW, WATER PUMP TO CYLINDER	1		
12		N.S.S.	STUD, WATER PUMP TO CYLINDER	1		
13		90840A	PULLEY, WATER PUMP (3 GROOVES)	1		
14	10	47277	SCREW, PULLEY TO WATER PUMP	4		
15	13	39107	LOCKWASHER, WATER PUMP	4		
16		11990	BALANCER, HARMONIC - CRANK	1		
17		33863	PULLEY, HARMONIC BALANCER	1		
18		90841A	PULLEY, (1 GROOVE) - W/POWER	1		
19	10	72626	BOLT, PULLEY AND HARMONIC BALANCER	1		
20	13	39131	LOCKWASHER, PULLEY AND HARMONIC BALANCER	1		
21	12	35332	WASHER, PULLEY AND HARMONIC BALANCER	1		
22	10	34352	BOLT, PULLEY (7/8") - W/O POWER	3		
22	10	35786	BOLT, PULLEY (1") - W/POWER	3		
23	13	35048	LOCKWASHER, PULLEY BOLT	3		
24	57	49213A	BELT, ALTERNATOR DRIVE (44")	1		
25		60660A	COVER, CRANKCASE FRONT	1		9
26	26	97335	OIL SEAL, COVER	1		9,4
27	27	34895	GASKET, COVER	1		9,4
25		14249A	COVER, CRANKCASE FRONT	1		8
26	26	97335	OIL SEAL, COVER	1		8,4
27	27	14250	GASKET, COVER	1		8,4
28	10	35366	SCREW, COVER	10		
29		11972	ADAPTOR, OIL FILTER	1		
30		41815	OIL FILTER	1		
31		42697	REINFORCEMENT, CRANKSHAFT	1		